



Instruction Manual
optoNCDT 1420

ILD 1420-10
ILD 1420-25
ILD 1420-50
ILD 1420-100
ILD 1420-200

ILD 1420-500

ILD 1420-10 CL1
ILD 1420-25 CL1
ILD 1420-50 CL1

Intelligent laser optical displacement measurement

MICRO-EPSILON
MESSTECHNIK
GmbH & Co. KG
Königbacher Straße 15

94496 Ortenburg / Germany

Tel. +49 (0) 8542 / 168-0
Fax +49 (0) 8542 / 168-90
e-mail info@micro-epsilon.de
www.micro-epsilon.com

Contents

1.	Safety	9
1.1	Symbols Used	9
1.2	Warnings	9
1.3	Notes on CE Identification	10
1.4	Proper Use	11
1.5	Proper Environment	11
2.	Laser Class	12
2.1	ILD1420	12
2.2	ILD1420 CL1	14
3.	Functional Principle, Technical Data	15
3.1	Short Description	15
3.2	Auto Target Compensation (ATC)	16
3.3	Technical Data ILD1420	17
3.4	Technical Data ILD1420-CL1	19
4.	Delivery	21
4.1	Unpacking	21
4.2	Storage	21
5.	Installation	22
5.1	Instructions for Installation	22
5.1.1	Reflection Factor of the Target Surface	22
5.1.2	Error Influences	22
5.1.2.1	Light from other Sources	22
5.1.2.2	Color Differences	23
5.1.2.3	Surface Roughness	23
5.1.2.4	Temperature Influences	23
5.1.2.5	Mechanical Vibration	23
5.1.2.6	Movement Blurs	23
5.1.2.7	Angle Influences	24
5.1.3	Optimizing the Measuring Accuracy	24
5.2	Mounting, Dimensions	25
5.3	Indicator Elements at Sensor	27

5.4	Electrical Connections.....	28
5.4.1	Connection Possibilities	28
5.4.2	Pin Assignment.....	30
5.4.3	Supply Voltage	31
5.4.4	Laser on.....	31
5.4.5	Analog Output	32
5.4.6	Multifunctional Input.....	33
5.4.7	RS422 Connection with USB Converter IF2001/USB.....	33
5.4.8	Digital Output.....	34
5.4.9	Connector and Sensor Cable.....	35
6.	Operation	36
6.1	Getting Ready for Operation	36
6.2	Operation via Web Interface	37
6.2.1	Preconditions.....	37
6.2.2	Access via Web Interface	39
6.2.3	Measurement Presentation via Web Browser.....	41
6.2.4	Video Signal via Web Browser	43
6.3	Programming via ASCII Commands	45
6.4	Timing, Measurement Value Flux	45
7.	Set Sensor Parameter	46
7.1	Preliminary Remarks to the Adjustments	46
7.2	Overview Parameter.....	46
7.3	Inputs	47
7.4	Signal Processing.....	47
7.4.1	Preliminary Remark	47
7.4.2	Measurement Task	48
7.4.3	Measuring Rate	49
7.4.4	Triggering.....	50
7.4.4.1	General.....	50
7.4.4.2	Signal Processing - Trigger for Acquiring Values	52
7.4.4.3	Signal Processing - Value Output Trigger	52
7.4.5	Mask Evaluation Area, ROI.....	53
7.4.6	Peak Selection	54
7.4.7	Error Handling	54

7.4.8	Averaging.....	55
7.4.8.1	General.....	55
7.4.8.2	Moving average.....	56
7.4.8.3	Recursive Average.....	57
7.4.8.4	Median.....	57
7.4.9	Zeroing and Mastering.....	58
7.4.9.1	Zeroing, Mastering with Select Key.....	59
7.4.9.2	Zeroing, Mastering with Hardware Input.....	60
7.4.10	Data Reduction, Output Data Rate.....	61
7.5	Outputs.....	62
7.5.1	Overview.....	62
7.5.2	Digital Output, RS422.....	63
7.5.2.1	Values, Ranges.....	63
7.5.2.2	Characteristics Digital Output.....	65
7.5.3	Analog Output Scaling.....	67
7.5.3.1	Output Scaling.....	67
7.5.3.2	Output Scaling with Key Select.....	68
7.5.3.3	Output Scaling via Hardware Input.....	69
7.5.3.4	Calculation of Measuring Value using Analog Current.....	70
7.5.3.5	Characteristics Distance Value and Analog Output.....	72
7.5.3.6	Mastering and Teaching Analog Output.....	74
7.6	System Settings.....	75
7.6.1	General.....	75
7.6.2	Unit, Language.....	75
7.6.3	Keylock.....	76
7.6.4	Load, Save.....	77
7.6.5	Import, Export.....	79
7.6.6	Access Authorization.....	80
7.6.7	Sensor Reset.....	81
8.	Digital Interfaces RS422.....	82
8.1	Preliminary Remarks.....	82
8.2	Measurement Data Format.....	82
8.3	Conversion of the Binary Data Format.....	83
9.	Cleaning.....	84
10.	Software Support with MEDAQLib.....	85

11.	Warranty	86
12.	Decommissioning, Disposal	86
13.	Service, Repair	86
Appendix		
A 1	Optional Accessories.....	87
A 2	Factory Setting.....	89
A 3	ASCII Communication with Sensor.....	90
A 3.1	General.....	90
A 3.2	Overview Commands.....	92
A 3.3	General Commands.....	95
A 3.3.1	HELP.....	95
A 3.3.2	GETINFO, Sensor Information.....	95
A 3.3.3	LANGUAGE, Website.....	95
A 3.3.4	RESET, Boot Sensor.....	96
A 3.3.5	RESETCNT, Reset Counter.....	96
A 3.3.6	ECHO, Switching the Command Reply, ASCII Interface.....	96
A 3.3.7	PRINT, Sensor Settings.....	97
A 3.3.8	User Level.....	98
A 3.3.8.1	LOGIN, Change of the User Level.....	98
A 3.3.8.2	LOGOUT, Change into User Level.....	98
A 3.3.8.3	GETUSERLEVEL, User Level Request.....	98
A 3.3.8.4	STDUSER, Set Standard User.....	98
A 3.3.8.5	PASSWD, Change Password.....	98
A 3.3.9	Triggering.....	99
A 3.3.9.1	TRIGGER, Selection.....	99
A 3.3.9.2	TRIGGERAT, Effect of the Trigger Input.....	99
A 3.3.9.3	MFILELEVEL, Input Pulse Multifunctional Input.....	99
A 3.3.9.4	TRIGGERCOUNT, Number of Displayed Measurement Values.....	99
A 3.3.9.5	TRIGGERSW, Software Trigger Pulse.....	100
A 3.3.10	Interfaces.....	100
A 3.3.10.1	BAUDRATE, RS422.....	100
A 3.3.10.2	UNIT, Web Interface.....	100
A 3.3.10.3	MFIFUNC, Function Selection Multifunctional Input.....	100
A 3.3.10.4	ERROROUT1, Activate Digital Output.....	100
A 3.3.10.5	ERRORLEVELOUT1, Output Level Digital Output.....	101
A 3.3.10.6	ERRORLIMIT.....	101

	A 3.3.10.7 ERRORHYSTERESIS	101
	A 3.3.10.8 ERROROUTHOLD	101
A 3.3.11	Handling of Setups.....	102
	A 3.3.11.1 IMPORT	102
	A 3.3.11.2 EXPORT.....	102
	A 3.3.11.3 MEASSETTINGS, Load / Save Measurement Settings	102
	A 3.3.11.4 BASICSETTINGS, Load / Save Device Settings.....	103
	A 3.3.11.5 SETDEFAULT, Default Settings	103
A 3.3.12	ANALOGSCALE, Scaling the Analog Output.....	103
A 3.3.13	Key Function.....	104
	A 3.3.13.1 KEYFUNC, Choose Key Function	104
	A 3.3.13.2 KEYLOCK, Set Keylock.....	104
A 3.4	Measurement.....	104
	A 3.4.1 TARGETMODE, Measurement Mode.....	104
	A 3.4.2 MEASPEAK, Choice of the Peak in the Video Signal	104
	A 3.4.3 MEASRATE, Measuring Rate	104
	A 3.4.4 LASERPOW, Laser Power	105
	A 3.4.5 ROI, Video Signal, Masking the Region of Interest (ROI)	105
	A 3.4.6 Measurement Value Processing.....	105
	A 3.4.6.1 AVERAGE, Measurement Value.....	105
	A 3.4.6.2 MASTERMV, Mastering / Zeroing.....	106
A 3.5	Data Output.....	106
	A 3.5.1 OUTPUT, Selection of Measurement Value Output	106
	A 3.5.2 OUTREDUCEDEVICE, Output Reduction of Measurement Value Output	106
	A 3.5.3 OUTREDUCECOUNT, Output Data Rate	107
	A 3.5.4 OUTHOLD, Error Processing	107
	A 3.5.5 Selection of Measurement Values to be Output	107
	A 3.5.5.1 GETOUTINFO_RS422, Request Data Selection.....	107
	A 3.5.5.2 OUTADD_RS422, Selection of Data Additional Values	107
	A 3.5.5.3 OUTVIDEO_RS422, Adjust Video Output.....	108
A 3.6	Example Command Sequence During Selection of Measurement Value.....	108
A 3.7	Error Messages.....	109
A 4	Control Menu	111
A 4.1	Tab Home.....	111
A 4.2	Tab Settings	111
	A 4.2.1 Inputs.....	111
	A 4.2.2 Signal Processing.....	112
	A 4.2.3 Outputs	114
	A 4.2.4 System Settings.....	116

1. Safety

The handling of the sensor assumes knowledge of the instruction manual.

1.1 Symbols Used

The following symbols are used in this instruction manual:



Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury.



Indicates a situation which, if not avoided, may lead to property damage.



Indicates a user action.



Indicates a user tip.

Measure

Indicates hardware or a button/menu in the software.

1.2 Warnings

Avoid unnecessary laser radiation to be exposed to the human body.



Switch off the sensor for cleaning and maintenance.



Switch off the sensor for system maintenance and repair if the sensor is integrated into a system.

Caution - use of controls or adjustments or performance of procedures other than those specified may cause harm.



Connect the power supply and the display-/output device in accordance with the safety regulations for electrical equipment.

> Danger of injury

> Damage to or destruction of the sensor

NOTICE

Avoid shock and vibration to the sensor.

> Damage to or destruction of the sensor

Mount the sensor only to the existing holes on a flat surface. Clamps of any kind are not permitted

> Damage to or destruction of the sensor

The power supply may not exceed the specified limits.

> Damage to or destruction of the sensor

Protect the sensor cable against damage. Attach the cable load-free, hold the cable after appr. 25 cm and hold the pigtail on the connector e.g. zip tie.

> Destruction of the sensor

> Failure of the measuring device

Avoid continuous exposure to fluids on the sensor.

> Damage to or destruction of the sensor

Avoid exposure to aggressive materials (washing agent, penetrating liquids or similar) on the sensor.

> Damage to or destruction of the sensor

1.3 Notes on CE Identification

The following applies to the optoNCDT 1420:

- EU directive 2014/30/EU
- EU directive 2011/65/EU, "RoHS" category 9

Products which carry the CE mark satisfy the requirements of the quoted EU directives and the European standards (EN) listed therein. The EC declaration of conformity is kept available according to EC regulation, article 10 by the authorities responsible at

MICRO-EPSILON MESSTECHNIK

GmbH & Co. KG

Königbacher Straße 15

94496 Ortenburg / Germany

The sensor is designed for use in industry and satisfies the requirements.

1.4 Proper Use

- The optoNCDT 1420 system is designed for use in industrial and laboratory areas.
- It is used
 - for measuring displacement, distance, position and thickness
 - for in-process quality control and dimensional testing
- The sensor may only be operated within the limits specified in the technical data, see Chap. 3.3.
- Use the sensor in such a way that in case of malfunctions or failure personnel or machinery are not endangered.
- Take additional precautions for safety and damage prevention for safety-related applications.

1.5 Proper Environment

- Protection class: IP 65 (applies only when the sensor cable is plugged in)

Lenses are excluded from protection class. Contamination of the lenses leads to impairment or failure of the function.

- Operating temperature: 0 °C ... 50 °C (+32 up to +104 °F)
- Storage temperature: -20 °C ... 70 °C (-4 up to +158 °F)
- Humidity: 5 - 95 % (non-condensing)
- Ambient pressure: Atmospheric pressure

• The protection class is limited to water, no penetrating liquids or similar!

2. Laser Class

2.1 ILD1420

The optoNCDT 1420 sensors operate with a semiconductor laser with a wavelength of 670 nm (visible/red). The sensors fall within Laser Class 2 (II). The laser is operated on a pulsed mode, the average power is ≤ 1 mW. The pulse frequency depends on the adjusted measuring rate (0.25 ... 4 kHz). The pulse duration of the peaks is regulated depending on the measuring rate and reflectivity of the target and can be 0.3 up to 3999.6 μ s.

CAUTION

Never deliberately look into the laser beam!
Consciously close your eyes or turn away immediately if ever the laser beam should hit your eyes.

i Comply with all regulations on lasers!

Although the laser output is low looking directly into the laser beam must be avoided. Due to the visible light beam eye protection is ensured by the natural blink reflex. The housing of the optical sensors may only be opened by the manufacturer, see Chap. 11. For repair and service purposes the sensors must always be sent to the manufacturer.

Lasers of Class 2 (II) are not subject to notification and a laser protection officer is not required.

The following warning labels are attached to the sensor cable.




Fig. 1 Laser warning labels on the sensor cable




Fig. 2 Laser warning labels on the sensor housing

During operation of the sensor the pertinent regulations acc. to IEC 60825-1 on „radiation safety of laser equipment“ must be fully observed at all times. The sensor complies with all applicable laws for the manufacturer of laser devices.

Laser operation is indicated by LED, see Chap. 5.3.




Fig. 3 True reproduction of the sensor with its actual location of the warning labels, ILD 1420

- i** If both warning labels are covered over when the unit is installed the user must ensure that supplementary labels are applied.

2.2 ILD1420 CL1

The optoNCDT 1420 CL1 sensors operate with a semiconductor laser with a wavelength of 670 nm (visible/red). The maximum optical power is ≤ 0.39 mW. The sensors fall within Laser Class 1 (I).

The accessible radiation is harmless under predictable conditions. Impairment of color vision and inconvenience may not be excluded for class 1 laser devices, e. g. through glare. The following warning labels are attached to the sensor cable:




Fig. 4 Laser warning labels on the sensor cable

Fig. 5 Laser warning labels on the sensor housing

Consequently, you can use Class 1 laser equipment without further protective measures. Class 1 lasers are not subject to registration and a laser protection officer is not required. Laser operation is indicated by LED, see Chap. 5.3. The housing of the optical sensors may only be opened by the manufacturer, see Chap. 11. For repair and service purposes the sensors must always be sent to the manufacturer.




Fig. 6 True reproduction of the sensor with its actual location of the warning labels, ILD 1420


3. Functional Principle, Technical Data

3.1 Short Description

The optoNCDT 1420 uses the principle of optical triangulation, that is, a visible, modulated point of light is projected onto the target surface.

The diffuse part of the reflection of this point of light is displayed depending on distance on a position-resolving element (CMOS) by an receiver optic which is arranged to the optical axis of the laser beam in a defined angle.

A signal processor in the sensor calculates the distance of the point of light on the measuring object to the sensor by means of the output signal of the CMOS elements. The distance value is linearized and output by means of the analog or RS422 interface.



Range = Measuring range
 SMR = Start of measuring range
 MR = Midrange
 EMR = End of measuring range

Fig. 7 Definition of terms

1) For distance values without zero setting resp. mastering only

3.2 Auto Target Compensation (ATC)

The Auto Target Compensation (ATC) enables stable compensation independent of color and brightness of the measuring object. Also small objects can be detected reliably thanks to the small measuring spot.

3.3 Technical Data ILD1420

Model	ILD1420-10	ILD1420-25	ILD1420-50	ILD1420-100	ILD1420-200	ILD1420-500	
Measuring range	10 mm	25 mm	50 mm	100 mm	200 mm	500 mm	
Start of measuring range	20 mm	25 mm	35 mm	50 mm	60 mm	100 mm	
Midrange	25 mm	37.5 mm	60 mm	100 mm	160 mm	350 mm	
End of measuring range	30 mm	50 mm	85 mm	150 mm	260 mm	600 mm	
Linearity ¹	8 ... 10 μm	20 ... 25 μm	40 ... 50 μm	80 ... 100 μm	160 ... 200 μm	500 ... 1000 μm	
	$\leq 0.08 - 0.1 \% \text{ FSO}$					$\leq 0.1 - 0.2 \% \text{ FSO}$	
Reproducibility ²	0.5 μm	1 μm	2 μm	4 μm	8 μm	20 ... 40 μm	
Measuring rate ³	0.25 kHz / 0.5 kHz / 1 kHz / 2 kHz / 4 kHz						
Light source	semiconductor laser <1 mW, 670 nm (red)						
Permissible ambient light	10,000 lx						
Spot diameter $\pm 10 \%$	SMR	90 x 120 μm	100 x 140 μm	90 x 120 μm	750 x 1100 μm	750 x 1100 μm	750 x 1100 μm
	MMR	45 x 40 μm	120 x 130 μm	230 x 240 μm			
	EMR	140 x 160 μm	390 x 500 μm	630 x 820 μm			
	smallest \varnothing	45 x 50 μm at 24 mm	55 x 50 μm at 31 mm	70 x 65 μm at 42 mm	---	---	---
Laser safety class	class 2 IEC 60825-1: 2015-07						
Temperature stability	$\pm 0.03 \% \text{ FSO}/^\circ\text{C}$						
Operation temperature	0 ... +50 $^\circ\text{C}$ (non-condensing)						
Storage temperature	-20 ... +70 $^\circ\text{C}$ (non-condensing)						
Output	analog	4 ... 20mA (1 ... 5V with cable PCF1420-3/U); 12 bit free scalable within the nominal range ⁴					
	digital	RS422 / 16 bit resp. 18 bit					
Vibration	20 g / 20 ... 500 Hz (acc. to IEC 60068-2-6)						

Shock		15 g / 6 ms / 3 axes (acc. to IEC 60068-2-29)
Weight		approx. 145 g (with cable 3m)
		approx. 60 g (with Pigtail)
Control I/O	input	laser on/off; functional input: trigger / zero-setting / mastering / teaching
	output	digital output
Sensor cable		3 m, integrated, open ends 0.3 m Pigtail with 12pin M12 connector
LED		2 x 3 color LEDs for power and status
Key		select key for zero / teaching / factory setting
Power supply		11-30 V DC, 24 V P < 2 W
Controller		integrated signal processor

The specified data apply for a diffusely reflecting matt white ceramic target.

FSO = Full scale output

SMR = Start of measuring range; MR = Midrange; EMR = End of measuring range

1) Values are valid from 0 to 50 % FSO resp. 51 to 100 % FSO.

2) Measuring rate 2 kHz, median 9

3) Factory setting 2 kHz; to change the factory setting requires an IF2001/USB converter (optionally available)

4) D/A conversion is executed with 12 bit

3.4 Technical Data ILD1420-CL1

Model		ILD1420-10CL1	ILD1420-25CL1	ILD1420-50CL1
Measuring range		10 mm	25 mm	50 mm
Start of measuring range		20 mm	25 mm	35 mm
Midrange		25 mm	37.5 mm	60 mm
End of measuring range		30 mm	50 mm	85 mm
Linearity ¹⁾		8 - 10 μm	20 - 25 μm	40 - 50 μm
		$\leq 0.08 - 0.1 \% \text{ FSO}$		
Reproducibility ²⁾		0.5 μm	1 μm	2 μm
Measuring rate ³⁾		0.25 kHz / 0.5 kHz / 1 kHz / 2 kHz / 4 kHz		
Light source		Halbleiterlaser $\leq 0.39 \text{ mW}$, 670 nm (rot)		
Permissible ambient light		10,000 lx		
Spot diameter $\pm 10 \%$	SMR	90 x 120 μm	100 x 140 μm	90 x 120 μm
	MMR	45 x 40 μm	120 x 130 μm	230 x 240 μm
	EMR	140 x 160 μm	390 x 500 μm	630 x 820 μm
	smallest \varnothing	45 x 40 μm bei 24 mm	55 x 50 μm bei 31 mm	70 x 65 μm bei 42 mm
Protection class		IP 65		
Laser safety class		Klasse 1 nach DIN EN 60825-1: 2015-07		
Temperature stability		$\pm 0.03 \% \text{ FSO}/^\circ\text{C}$		
Operation temperature		0 ... +50 $^\circ\text{C}$ (non-condensing)		
Storage temperature		-20 ... +70 $^\circ\text{C}$ (non-condensing)		
Output	analog	4...20 mA (1-5 V with cable PCF1420-3/U); 12 bit; free scalable within the nominal range ⁴⁾		
	digital	RS422 / 16 bit		
Vibration		20 g / 20 ... 500 Hz (nach IEC 60068-2-6)		

Schock		15 g / 6 ms / 3 axes (acc. to IEC 60068-2-29)
Weight		appr. 145 g (with cable 3 m)
		appr. 60 g (with Pigtail)
Control I/O	input	laser on/off; funktional input: trigger / zero-setting / mastering / teaching
	output	digital output
Sensor cable		3 m, integrated, open ends 0.3 m Pigtail with 12pin M12 connector
LED		2 x 3 color LEDs for power and status
Key		select key for zero / teaching / factory setting
Power supply		11-30V DC, 24 V, P < 2 W
Controller		integrated signal processor

The specified data apply for a diffusely reflecting matt white ceramic target.

FSO = Full scale output

SMR = Start of measuring range; MR = Midrange; EMR = End of measuring range

1) Values are valid from 0 to 50 % FSO resp. 51 to 100 % FSO.

2) Measuring rate 2 kHz, median 9

3) Factory setting 2 kHz; to change the factory setting requires an IF2001/USB converter (optionally available)

4) D/A conversion is executed with 12 bit;

4. Delivery

4.1 Unpacking

- 1 Sensor ILD 1420
- 1 Assembly instruction
- 1 CD with program <ILD1420 DAQ Tool.exe> and instruction manual
- 1 Calibration protocol
- Accessories (2 pieces screw M2 and 2 pieces washer)

- ➡ Carefully remove the components of the measuring system from the packaging and ensure furthermore that the goods are forwarded in such a way that no damage will occur.
- ➡ Check the delivery for completeness and shipping damage immediately after unpacking.
- ➡ In case of damage or missing parts, please contact the manufacturer or supplier immediately.

See Appendix for further accessories, see Chap. [A 1](#)

4.2 Storage

Storage temperature: -20 up to +70 °C (-4 °F up to +158 °F)

Humidity: 5 - 95 % (non-condensing)

5. Installation

5.1 Instructions for Installation

5.1.1 Reflection Factor of the Target Surface

In principle the sensor evaluates the diffuse part of the reflected laser light.




Fig. 8 Reflection factor of the target surface

A statement concerning a minimum reflectance is difficult to make because even a small diffuse fraction can be evaluated from highly reflecting surfaces. This is done by determining the intensity of the diffuse reflection from the CMOS signal in real time and subsequent compensation, see Chap. 3.2. Dark or shiny objects being measured, e.g. black rubber, may require longer exposure times. The exposure time is dependent on the measuring rate and can only be increased by reducing the sensor's measuring rate.

5.1.2 Error Influences

5.1.2.1 Light from other Sources

Thanks to their integrated optical interference filters the optoNCDT 1420 sensors offer outstanding performance in suppressing light from other sources. However, this does not preclude the possibility of interference from other light sources if the objects being measured are shiny and if lower measuring rates are selected. Should this be the case it is recommended to use suitable shields to screen the other light sources. This applies in particular to measurement work performed in close proximity to welding equipment.

5.1.2.2 Color Differences

Because of intensity compensation, color difference of targets affect the measuring result only slightly. However, such color differences are often combined with different penetration depths of the laser light into the material. Different penetration depths then result in apparent changes of the measuring spot size. Therefore color differences in combination with changes of penetration depth may lead to measuring errors.

5.1.2.3 Surface Roughness

In case of traversing measurements surface roughnesses of $5\ \mu\text{m}$ and more lead to an apparent distance change (also-called surface noise). However, they can be dampened by averaging.

5.1.2.4 Temperature Influences

When the sensor is commissioned a warm-up time of at least 20 minutes is required to achieve uniform temperature distribution in the sensor. If measurement is performed in the micron accuracy range, the effect of temperature fluctuations on the sensor holder must be considered. Due to the damping effect of the heat capacity of the sensor, sudden temperature changes are only measured with delay.

5.1.2.5 Mechanical Vibration

If the sensor is to be used for resolutions in the μm to sub- μm range, special care must be taken to ensure stable and vibration-free mounting of sensor and target.

5.1.2.6 Movement Blurs

If the objects being measured are fast moving and the measuring rate is low, it is possible that movement blurs may result. Always select a high measuring rate for high-speed operations, therefore, in order to prevent errors.

5.1.2.7 Angle Influences

Tilt angles of the target in diffuse reflection both around the X and the Y axis of less than 5 ° only have a disturbing effect with surfaces which are highly reflecting.

These influences have to be explicitly considered when scanning profiled surfaces. Basically the angle behavior of triangulation is liable to the reflectivity of the measuring object surface.






Fig. 9 Measurement errors through tilting with diffuse reflection

5.1.3 Optimizing the Measuring Accuracy



In case of rolled or polished metals that are moved past the sensor the sensor plane must be arranged in the direction of the rolling or grinding marks. The same arrangement must be used for color strips.

Fig. 10 Sensor arrangement in case of ground or striped surfaces



In case of bore holes, blind holes and edges in the surface of moving targets the sensor must be arranged in such a way that the edges do not obscure the laser spot.

Fig. 11 Sensor arrangement for holes and ridges

5.2 Mounting, Dimensions

The optoNCDT 1420 sensor is an optical system for measurements with micrometer accuracy. The laser beam must be directed perpendicularly onto the surface of the target. In case of misalignment it is possible that the measurement results will not always be accurate.

i Make sure it is handled carefully when installing and operating.

➡ Mount the sensor by means of 2 screws type M3 or by means of through bores for M2 with the screws from the accessories.

Bolt connection					
Through length	Screw depth	Amount	Screw	Washer	Torque
20 mm	min 5 mm	2	M2 x 25 ISO 4762-A2	A2.2 ISO 7089-A2	0.5 Nm ($\mu = 0.2$)
	min 4.8 mm, max 20 mm	2	M3 ISO 4762-A2		1 Nm ($\mu = 0.12$)
Direct fastening					

Fig. 12 Mounting conditions

The bearing surfaces surrounding the fastening holes (through-holes) are slightly raised.

i Mount the sensor only to the existing holes on a flat surface. Clamps of any kind are not permitted. Do not exceed torques.




Fig. 13 Dimensional drawing and free space for optics




Fig. 14 Dimensional drawing M12 cable connector

ILD 1420-		10	25	50	100	200	500
MR	mm	10	25	50	100	200	500
SMR	mm	20	25	35	50	60	100
EMR	mm	30	50	85	150	260	600
Y	mm	10	21	28	46	70	190


The indicated free space in the reception area, see Fig. 13, has to be kept clear from foreign objects and extraneous light of other laser sensors at least until the end of measuring range.

- MR = Measuring range
- SMR = Start of measuring range
- MR = Midrange
- EMR = End of measuring range
- FSO = Full scale output

A: 2x M3 for direct fastening or
2x M2 for bolt connection

5.3 Indicator Elements at Sensor

LED State	Meaning
green	Measuring object within sensor range
yellow	Mid range
red	Error - e.g. Poor target or out of range
off	Laser off
LED Output	Meaning
green	RS422 measurement value output
yellow	RS422 and current output are switched off. The RS422 and the current output can be switched on. Web interface can also be switched on.
red	Current 4 ... 20 mA measurement value output
off	Sensor off, no supply



The programmable touch key `select` calls up the functions `Masters` and `Teaching`. By factory default this key is only active for the first 5 minutes after power up. After that it will be automatically locked. The keylock can be programmed via internal websites or ASCII commands.

5.4 Electrical Connections

5.4.1 Connection Possibilities





Fig. 15 Connection examples on ILD 1420

The different periphery devices can be connected by the illustrated connection cables to the 14-pin sensor plug, see Fig. 15. The converters IF2001/USB, IF2004/USB and the PCI interface card IF2008 also supply the operating voltage (24 V DC) of the sensor. Power to the converters is supplied e. g. by the optional power supply PS 2020.


Peripheral	Sensor channels	Interface
IF2001/USB, RS422 USB converter	one	RS422
IF2004/USB	four	
IF2008, PCI interface card	four	
SPS, ILD 1420 or the like	---	Functional input: trigger
Switch, key, PLC or the like	---	Switching input laser On/Off

Fig. 16 Max. sensor channels on the peripheral devices

5.4.2 Pin Assignment




ILD1420 with pigtail



ILD1420 with open ends

The shielding of the cable is connected to the sensor housing. The sensor cable is not cable carriers suitable. One end is molded on the sensor, the other end has free leads with ferrules or a pigtail with a M12 male connector.


Pin	Sensor cable resp. PCF1420-x/I, description		Specification	 <p>Solder pin side female cable connector</p>
3	green	RS422 Rx+	Serial input	
4	yellow	RS422 Rx-		
5	gray	RS422 Tx+	Serial output	Terminate externally with 120 Ohm
6	pink	RS422 Tx-		
7	red	+U _B	Supply voltage	11 ... 30 VDC, typ. 24 VDC, P < 2 W
8	black	Laser on/off	Switch input	Laser is active, if input is connected with GND
9	violet	Functional input		Trigger, Zero/Master, Teaching
10	brown	Error	Switch output	I _{max} = 100 mA, U _{max} = 30 VDC, Programmable switching characteristic: (NPN, PNP, Push-Pull)
11	white	I _{OUT}	4 ... 20 mA	R _{Load} = 250 Ohm: U _{OUT} 1 ... 5 V with U _B > 11 V R _{Load} = 500 Ohm: U _{OUT} 2 ... 10 V with U _B > 17 V
12	blue	GND	Ground potential	Supply and signal ground
	Shield	Connector housing	Sensor housing	Connect with potential equalization

The sensor cable PCF1420 is cable carriers suitable. One end is molded on the sensor, the other end has free leads with ferrules or a pigtail with a M12 male connector.

5.4.3 Supply Voltage

Nominal value: 24 V DC (11 ... 30 V, $P < 2$ W).

- ➡ Switch on the power supply unit once wiring is completed.
- ➡ Connect the inputs "7" and "12" at the sensor with a 24 V voltage supply.




Use the supply voltage for measurement instruments only and not for drive units or similar sources of pulse interference at the same time. MICRO-EPSILON recommends using an optional available power supply unit PS2020 for the sensor.

Fig. 17 Connection of supply voltage

5.4.4 Laser on

The measuring laser on the sensor is activated via an HTL switch input. This is advantageous if the sensor has to be switched off for maintenance or similar. Switching can be done with a transistor (for example open collector in an optocoupler) or a relay contact.

i If pin 8 is not connected with Pin 12, the laser is off.



There is no external resistor for current limiting required. Connect Pin 8 with Pin 12 for permanent „Laser on“.

Reaction Time for Laser-On: Correct measuring data are sent by the sensor approximately 1 ms after the laser was switched on.

Fig. 18 Electrical wiring for laser off


5.4.5 Analog Output

The sensor provides a current output 4 ... 20 mA.

i The output may not be continuously operated in short circuit operation without load resistor. The short circuit operation leads to durable thermal overload and thus for automatic overload shutdown of the output.

➔ Connect the output 11 (white) and 12 (blue) on the sensor to a measuring device.

Sensor	
12-pin M12 cable connector	Sensor cable
I_{OUT} (Pin 11)	white
GND (Pin 12)	blue



When using a PCF1420-x/U you will get an analog voltage at the output in the range of 1 ... 5 V.

$R = 250 \text{ Ohm}$:

$U_{OUT} 1 \dots 5 \text{ V at } U_B > 11 \text{ V}$

$R = 500 \text{ Ohm}$:


$U_{OUT} 2 \dots 10 \text{ V at } U_B > 17 \text{ V}$

Fig. 19 Wiring for voltage output

1) The components are already included in PCF 1420-x/U.

5.4.6 Multifunctional Input

The multifunctional input enables the functions Triggering, Zeroing/Mastering, Teaching. The function is dependent on the programming of the input and of the time behavior of the input signal.



The input is not galvanically isolated. Internal pull up resistance, an open input is noticed as High. Connect the input with GND to trigger the function.


Fig. 20 Electrical wiring for multifunctional input

5.4.7 RS422 Connection with USB Converter IF2001/USB

Cross the lines for connections between sensor and PC.

i Disconnect or connect the D-sub connection between RS422 and USB converter when the sensor is disconnected from power supply only.

Sensor		End device (converter)
12-pin M12 cable connector	Sensor cable	Type IF2001/USB from MICRO-EPSILON
Tx + (Pin 5)	grey	Rx + (Pin 3)
Tx -(Pin 6)	pink	Rx -(Pin 4)
Rx + (Pin 3)	green	Tx + (Pin 1)
Rx -(Pin 4)	yellow	Tx -(Pin 2)
GND (Pin 12)	blue	GND (Pin 9)



Symmetric differential signals acc. to EIA-422, not galvanically isolated from supply voltage.


Use a shielded cable with twisted cores e.g. PCF1420-x.

Fig. 21 Pin assignment IF2001/USB

5.4.8 Digital Output

The switching characteristic (NPN, PNP, Push-Pull, Push-Pull negated) of the digital output (Error) depends on the programming.

The NPN output is e.g. suitable for adjustment to TTL logics with an auxiliary voltage $U_H = +5\text{ V}$. The digital output is protected against reverse polarity, overloading ($< 100\text{ mA}$) and over temperature.



Output is not galvanically isolated.
 24V logics (HTL),
 $I_{\max} = 100\text{ mA}$,
 $U_{H\max} = 30\text{ V}$ saturation voltage at $I_{\max} = 100\text{ mA}$:
 Low $< 2.5\text{ V}$ (output - GND),
 High $< 2.5\text{ V}$ (output - $+U_B$)


Fig. 22 Electrical wiring digital output

Switching characteristic		
Description	Output active (error)	Output passive (no error)
NPN (Low side)	GND	appr. $+U_H$
PNP (High side)	$+U_B$	appr. GND
Push-Pull	$+U_B$	GND
Push-Pull, negated	GND	$+U_B$


Fig. 23 Switching characteristic digital output

Digital output is activated when measuring object is missing, measuring object too close/too far or when no valid measurement value can be determined.

5.4.9 Connector and Sensor Cable



ILD 1420 with pigtail



ILD 1420 with open ends

➡ Never fall below the bending radius for the sensor cable of 30 mm (fixed) resp. 60 mm (dynamic).



The fixed connected sensor cables are not cable carriers suitable.



Unused open cable ends must be insulated to protect against short circuits or malfunction of the sensor.

MICRO-EPSILON recommends to use the cable carriers suitable standard connection cable of the optional accessories, see Chap. A 1.

- ➡ Mount the 12-pin M12 cable connector if you use a cable carriers suitable sensor cable PCF1420.
- ➡ Avoid excessive pulling to the cables. Provide strain relieves near the connectors when cables > 5 m are vertically free hanging.
- ➡ Connect the cable shield to the potential equalization (PE, protective earth conductor) on the evaluator (control cabinet, PC housing) and avoid ground loops.
- ➡ Never lay signal leads next to or together with power cables or pulse-loaded cables (e.g. for drive units and solenoid valves) in a bundle or in cable ducts. Always use separate ducts.

Recommended strand cross-section for self-made connection cables: $\geq 0.14 \text{ mm}^2$ (AWG 25).

6. Operation

6.1 Getting Ready for Operation

- ▶ Install and assemble the optoNCDT 1420 in accordance with the instructions set out, see Chap. 5.
- ▶ Connect the sensor with the indicator or monitoring unit and the power supply.

The laser diode in the sensor can only be activated if at the input Laser on/off Pin 8 is connected with Pin 12, see Chap. 5.4.4.

Once the operating voltage has been switched on the sensor runs through an initialization sequence. This is indicated by the momentary activation of all the LEDs. Once initialization has been completed, the sensor transmits a „->“ via the RS422 interface. The initialization takes up to 10 seconds. Within this period, the sensor executes the `Reset` resp. the `Bootloader` command through the key `select` only.

To be able to produce reproducible measurements the sensor typically requires a start-up time of 20 minutes.

If the LED `output` is off, this means that there is no supply voltage.

If the LED `state` is off, this means that the laser light source has been switched off.

6.2 Operation via Web Interface

6.2.1 Preconditions

In the sensor, dynamic Web pages are created that contain the current settings of the sensor and the periphery. The operation is only possible as long as an RS422 connection to the sensor exists.

The sensor is connected to a PC/notebook via a RS422 converter, supply voltage persists.

➡ Start the program `ILD1420 DAQ Tool Vx.x.x.`





Fig. 24 Auxiliary program for sensor search and to start web interface

The ILD 1420 DAQ tool searches for connected ILD 1420 sensors by means of an internal auxiliary program on available interfaces.

You need a web browser (e.g. Mozilla Firefox or Internet Explorer) on a PC/notebook.

- ➡ Choose the desired sensor. Click on the button **Connect**.
- ➡ Choose **Configuration** in the menu **Extras**.
- ➡ Choose the browser type in dialog **Configuration** and click on the button .





Fig. 25 Dialog configuration web interface

6.2.2 Access via Web Interface

➔ Start the web interface of the sensor, see Chap. 6.2.1

Interactive websites for programming the sensor now appear in the web browser.







In the top navigation bar other auxiliary functions (settings, measurement chart etc.) are available.

The appearance of the web-sites can change dependent of the functions. Each page contains descriptions of parameters and so tips for filling the website.

Fig. 26 First interactive web-site after selection of the web interface

The sensor is active and supplies measurement values. The ongoing measurement can be operated by means of function buttons in the area `Measurement`.

By clicking the button  in the area `Measurement configuration`, the change between the saved configurations (presets) for different measuring object surfaces (targets) is done. Choosing a target causes a predefined configuration of the settings which achieves the best results for the chosen material.

Stored configurations		
Presets		
 Standard	Standard	Ceramics, metal
 Multi-Surface	Multi-surface ¹	Printed circuit boards (PCB), hybrid material
 Light Penetration	Light penetration ¹	Plastics (Teflon, POM), Materials with large penetration depth of the laser

In the area `Signal quality` you can switch between four given basic settings (static, balanced, dynamic and no averaging). You can instantly see the reaction in the diagram and system configuration.

The area `System configuration` displays the current settings for measuring rate, averaging and RS422 in blue lettering. Changes to the settings are possible by means of the slide `Signal quality` or by means of the tab `Settings`.

The area `Diagram type` enables the change between graphical display of the measurement value or the video signal, each as value time diagram.

i After programming all the settings are to be stored permanently in a set of parameters. The next time you turn on the sensor they are available again.

Therefore use the button `Save settings`.

i If the sensor starts with user defined measurement setting (setup), see Chap. 7.6.4, changing the signal quality is not possible.

1) Available for the sensor models ILD1420-10/25/50.

6.2.3 Measurement Presentation via Web Browser

➔ Start the measurement value display (Measurement chart) in the horizontal navigation bar.




Fig. 27 Website measurement (distance measurement)

- 1 Stop stops the diagram; data selection and zoom function are still possible. Pause interrupts recording. Save opens the Windows selection dialog for file name and storage location to save the last 10,000 values in a CSV file (separation with semicolon).
- 2 This function starts resp. stops a relative measurement. The master value can also be defined in a submenu here.

- 3 For scaling the measurement value axis (y-axis) of the graphics you can either choose `Auto` (= auto-scaling) or `Manual` (= manual setting).
- 4 The search function enables time-saving access to functions and parameters.
- 5 In the text boxes above the graphics current values for distance, exposure time, current measuring and display rate and timestamp are displayed.
- 6 Choice of a diagram type. In the setting `Auto` the diagram type matching the setting is chosen automatically.
- 7 Mouse over function. When moving the mouse over the graphic in stopped state curve points are marked with a circle symbol and the related values are displayed in text boxes above the graphic. Peak intensity is also updated.
- 8 The peak intensity is displayed as bar chart.
- 9 Scaling of the x-axis can be defined by means of a input field below the time axis.
- 10 Scaling of the x-axis: you can enlarge (zoom) the overall signal by means of the left slider during ongoing measurement. If the diagram is stopped, you can also use the right slider. The zoom window can also be moved by means of the mouse in the middle of the zoom window (arrow cross).

i If you leave the diagram display in a separate tab or window of the browser running, you do not have to restart the description each time.

 Click the button `Start`, for starting the display of the measurement results.

6.2.4 Video Signal via Web Browser

➡ Start the video signal display with the function `Video` in the area `Diagram type`.

The diagram in the big graphic window on the right displays the video signal of the recipient filed. The video signal in the graphic window displays the intensity distribution above the pixels of the recipient field. 0 % (distance small) on the left and 100 % (distance big) on the right. The related measurement value is marked by means of a vertical line (peak marking).




Fig. 28 Display of video signals

- 1 Stop stops the diagram; data selection and zoom function are still possible. Pause interrupts recording. Save opens the Windows selection dialog for file name and storage location to save the last 10,000 values in a CSV file (separation with semicolon).
- 2 This function starts resp. stops a relative measurement. The master value can also e defined in a submenu here.

- 3 The video curves to be displayed while or after measurement can be switched on or off in addition in the left window. Non active curves are highlighted in gray and can be added by clicking the hook. If you only want to see a single signal, then click on its name.
 - Raw signal (uncorrected CMOS signal, red)
 - Peak marking (vertical blue line), corresponds to the calculated measurement value
 - Linearized measuring range (limited by means of gray shading), cannot be changed
 - Masked range (limited by means of light blue shading), changeable
- 4 For scaling the measurement value axis (y-axis) of the graphics you can either choose `Auto` (= auto scaling) or `Manual` (= manual setting).
- 5 The search function enables time-saving access to functions and parameters.
i ASCII commands to the sensor can also be sent via the search function.
- 6 In the text boxes above the graphics current values for distance, exposure time, current measuring and display rate and timestamp are displayed.
- 7 Choice of a diagram type. In the setting `Auto` the diagram type matching the setting is chosen automatically.
- 8 Mouse over function. When moving the mouse over the graphic in stopped state curve points are marked with a circle symbol and the related intensity is displayed. The related x position in % appears above the graphic filed.
- 9 The linearized range is between the gray shading in the diagram and cannot be changed. Only peaks which centers are within this range can be calculated as measurement value. The masked range can be limited on request and is additionally limited by means of a light blue shading on the right and on the left. The remaining peaks in the resulting range are used for evaluation.
- 10 Scaling of the x-axis can be defined by means of a input field below the time axis.
- 11 Scaling of the x-axis: you can enlarge (zoom) the overall signal by means of the left slider during ongoing measurement. If the diagram is stopped, you can also use the right slider. The zoom window can also be moved by means of the mouse in the middle of the zoom window (arrow cross).

By displaying the video signal, you can detect effect of the adjustable measurement task (target material), choice of peak and possible interfering signals by means of reflections.

There is no linear relationship between the position of the peaks in the video signal and the output measurement value.

6.3 Programming via ASCII Commands

As an added feature you can program the sensor via an ASCII interface, physically the RS422. This requires, that the sensor must be connected either to a serial RS422 interface via a suitable interface converter, see Chap. [A 1](#), or a plug-in-card to a PC / PLC.

Pay attention in the programs used to the correct RS422 default setting.

Once connected, you can transmit the commands from the appendix, see Chap. [A 3](#), via the terminal to the sensor.

6.4 Timing, Measurement Value Flux

The sensor requires three cycles for measurement and calculation without triggering:

Each cycle takes 250 μ s at a measuring rate of 4 kHz. The measured value N is available at the output after three cycles. The delay between acquisition and output is therefore 750 μ s. As the processing in the cycles occurs parallel, after another 250 μ s, the next measured value (N+1) is output.

7. Set Sensor Parameter

7.1 Preliminary Remarks to the Adjustments

You can program the optoNCDT 1420 simultaneously in two different ways:

- using a web browser via the ILD 1420 DAQ Tool and the Web interface
- ASCII command set and a terminal program via RS422.



If you do not save the programming permanently in the sensor, you lost the settings after turning off the sensor.

7.2 Overview Parameter

The following parameters can be set or changed in the optoNCDT 1420, see tab *Settings*.

Inputs	Laser on/off, Multifunctional input, Key function
Signal processing	Measurement task, Measuring rate, Reset counter, Triggering (Data recording, Data output), Evaluation range (ROI), Peak selection, Error handling, Averaging, Zeroing/Mastering, Data reduction
Outputs	RS422, Analog output, Digital output
System settings	Unit on website, Keylock, Setup management, Import & Export, Access authorization, Reset controller (factory settings)

7.3 Inputs

➡ Go to the menu `Inputs` in the menu `Settings`.

Laser on/off	On / Off		Laser on/off is only effective when pin 8 is connected to GND.
Multifunctional input	Zeroing (Mastering)	High / Low	Sets the function of the digital input. The Trigger influences capture and export of a measurement value. Zeroing/Mastering sets the current measurement value to the entered master value. Teaching scales the analog output. HTL is defined as active input level.
	Trigger In	High / Low	
	Teaching		
	Inactive		
Key function	Zeroing (Mastering)		Sets the function of the sensor key. Inactive means keylock.
	Teaching		
	Inactive		

7.4 Signal Processing


7.4.1 Preliminary Remark

➡ Go to the menu `Signal processing` in the tab `Settings`.

A diagram appears according to the prior settings in the area `Diagram type` in the right part of the display. The diagram is active and various settings can be seen immediately. You can find references to the chosen setting below.

The menus for the area `Signal processing` are located in the left part.


 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.


7.4.2 Measurement Task

The measurement task contains choice of the measuring object (target). The choice of a target loads a pre-defined sensor configuration which achieves the best results for the chosen material.

Measurement task	<i>Standard</i>	<i>Suitable for materials made of ceramics, metal or filled plastics</i>
	<i>Changing surfaces 1</i>	<i>Suitable e.g. for Printed circuit boards (PCB) or hybrid materials</i>
	<i>Material with penetration 1</i>	<i>Suitable for plastics (POM, Teflon), materials with large penetration depth of the laser</i>



Setting: Standard



Material with penetration

The choice of measuring object preferences can be observed in the diagram Video signal on the right by means of the position of the blue peak marking in relation to the video signal (raw signal). It should preferably hit in the area of the highest point (peak) of the video signal.

Fig. 29 Example: Video signals (extract) with measuring object material POM

In the setting `Standard` the peak marking (measurement value) of the plastics example POM does not hit the focus of the real peak as its base is distorted asymmetrically by means of penetration of the laser light. This is possible only if the measurement task was set to `Material with penetration`.

In the setting `Changing surfaces` a compromise between penetration and standard finish is chosen which achieves optimum results for both materials. This can also be seen in the diagram distance values (`Meas`) by means of the different distance values for the respective measurement tasks.

1) Available for the sensor models ILD1420-10/25/50.

Grey shaded fields require a selection.

Dark-bordered fields require you to specify a value.

7.4.3 Measuring Rate


The measuring rate indicates the amount of measurements per second.


 Choose the desired measuring rate.

Measuring rate	250 Hz / 500 Hz / 1 kHz / 2 kHz / 4 kHz	<i>Use a high measuring rate with light and matt measuring objects. Use a low measuring rate with dark and shiny measuring objects (e.g. black lacquered surfaces) to improve the measuring result.</i>
----------------	--	---

With a maximum measuring rate of 4 kHz the CMOS element is exposed 4,000 times per second. The lower the measuring rate, the higher maximum exposure time.

Measuring rate is set to 2 kHz ex works.

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

7.4.4 Triggering

7.4.4.1 General


The optoNCDT 1420 measurement input and output is controllable through an external trigger signal or a command. Triggering affects the analog and digital output. The measurement value at the time of triggering is output delayed, see Chap. 6.4.

- Triggering does not influence the measuring rate resp. the timing so that between the trigger event (level change) and the start of output always lie 3 cycles + 1 cycle (Jitter).
- Micro-Epsilon recommends the abdication of data reduction, for example, by sub-sampling when the triggering is used.
- The multifunctional input is used as external trigger input, see Chap. 5.4.6.
- Factory setting: no triggering, the sensor starts data transmission right after start-up.
- Pulse duration of the "Trigger in" signal must be at least 50 μ s.

Triggering of measured value acquisition and output have the same time behavior.

<i>Input trigger</i> / <i>Output trigger</i>	<i>Level</i>			<i>A continuous measurement task is following as long as the chosen level remains the same. Choice of level, see Chap. 7.3. Pulse duration must be at least a cycle time. The following pause must be at least a cycle time..</i>	
	<i>Edge</i>	<i>infinite</i>			<i>Edge selection, see Chap. 7.3. "0" end trigger, "1 ... 16382" values per trigger, "16383" endless trigger</i>
		<i>manual</i>	<i>Number</i>	<i>Value</i>	
	<i>Software</i>	<i>infinite</i>			<i>A software triggering is started by clicking the button Release trigger. "0" end trigger "1 ... 16382" values per trigger, "16383" endless trigger</i>
		<i>manual</i>	<i>Number</i>	<i>Value</i>	
<i>Inactive</i>				<i>No triggering</i>	

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

Implemented trigger conditions:

Level triggering with high level / low level.

Continuous measurement input resp. output, as long as the selected level is applied. Then stops the data output.

The pulse duration must be at least one cycle time. The subsequent break must also be at least one cycle time.




Fig. 30 High trigger level (above) with analog output A_0 and digital output signal D_0 (below)

Edge triggering with rising or falling edge.

Starts measured value acquisition resp. output as soon as the chosen edge is applied to the trigger input. The sensor outputs a fixed number of measurement values when trigger conditions have been met. Value range from 1 ... 16383. After termination of data output the analog output sticks to the last value (sample & hold).

Pulse duration must be at least 50 μ s.




Fig. 31 Trigger edge HL (above) with analog output A_0 and digital output signal D_0 (below)

Software triggering. Starts the measurement value output, when a software command comes. The trigger time is defined more inaccurately. After the trigger event the sensor outputs the preset number of measurement values or starts a continuous measurement value output. If "0" is selected for the number of measurement values, the sensor stops the triggering and the continuous value output.

Measurement output can also be stopped by means of a command.

7.4.4.2 Signal Processing - Trigger for Acquiring Values

The current field signal is processed only after a valid trigger event, and it is used to calculate the measurement values. The measurement values are then forwarded for further calculation (e.g. averaging) and for output via an analog or a digital interface.

When calculating averages, measurement values recorded immediately before the trigger event cannot be included; instead older measurement values are used, which were recorded during previous trigger events. Activating data recording trigger deactivates data output trigger.

7.4.4.3 Signal Processing - Value Output Trigger

Measurement values are calculated continuously and independently of the trigger event. A trigger event simply triggers the value output via a digital interface. Therefore, any values measured immediately before the trigger event are included in calculating mean values (averages).

Activating data output trigger deactivates data recording trigger.

7.4.5 Mask Evaluation Area, ROI

Masking limits evaluation area (ROI - Region of interest) for distance calculation in the video signal. This function is used to suppress e.g. disturbing reflections or extraneous light.




Fig. 32 Light blue areas limit the evaluation area

The exposure control optimizes the peaks in the evaluation range. Thus, small peaks can be optimally controlled when a high interfering peak is outside the evaluation range.

7.4.6 Peak Selection

Peak selection	<i>First peak / highest peak / last peak</i>	<p>Defines, which signal is used for the evaluation in the line signal.</p> <p>First peak: nearest peak to the sensor.</p> <p>Highest peak: standard, peak with the highest intensity.</p> <p>Last Peak: widest peak to the sensor.</p>	
----------------	--	---	--

A correct measuring result can be determined only for the first peak when a measuring object which consists of several transparent layers.

7.4.7 Error Handling

Error handling adjusts the behavior of the analog output and the RS422 interface in the event of an error.

Error handling	Error output, no value	<i>Analog output supplies 3 mA instead of the measurement value. The RS422 interface outputs an error value.</i>	
	Retain last value infinitely	<i>Analog output and RS422 interface stick to the latest valid value.</i>	
	Retain last value	1 ... 1024	Value

If no valid measurement value can be detected, an error is output. If this disrupts further processing, you can alternatively hold the last valid value over a specific period of time i.e. it can be output again. After expiry of the chosen number an error value is output.

Grey shaded fields require a selection.

Dark-bordered fields require you to specify a value.

7.4.8 Averaging

7.4.8.1 General

The averaging is recommended for static measurements or slowly changing values.

Averaging	<i>Inactive</i>			<i>Measurements are not averaged.</i>
	<i>Moving N values</i>	2 / 4 / 8 ... 128	<i>Value</i>	<i>Indication of averaging mode. The averaging number N indicates the number of consecutive measurement values to be averaged in the sensor.</i>
	<i>Recursive N values</i>	2 ... 32768	<i>Value</i>	
	<i>Median N values</i>	3 / 5 / 7 / 9	<i>Value</i>	

The averaging of measurement values is effected after the calculation of the displacement values prior to the output via the interfaces.

The purpose of averaging is to:

- Improve the resolution
- Eliminate signal spikes or
- „Smooth out“ the signal.

Averaging has no effect on linearity.


In completion of the measuring cycle the internal average is calculated again.

i The preset average value and the number of averaging are to save in the sensor, so that they remain after switching off.

Averaging does not affect the measuring rate or data rates in digital measurement value output. The averaging numbers can also be used if programmed via the digital interfaces. The sensor optoNCDT 1420 is supplied ex factory with the default setting „Median 9“, that is, averaging with Median and 9 measurements.

Depending on the average type and the averaging number there is a different settling time, see Chap. 6.4.

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

7.4.8.2 Moving average

The selected number N of successive measurement values (window width) is used to generate the arithmetic average value M_{gl} on the basis of the following formula:

$$M_{gl} = \frac{\sum_{k=1}^N MV(k)}{N}$$

MV = Measurement value,

N = Averaging number,

k = Running index

M_{gl} = Averaging value respectively output value

Mode:

Each new measurement value is added and the first (oldest) measurement value from the averaging process (from the window) taken out again. This results in short transient recovery times for jumps in measurement values.

Example with N = 4

... 0, 1, 2, 2, 1, 3

↓

$$\frac{2, 2, 1, 3}{4} = M_{gl}(n)$$

... 1, 2, 2, 1, 3, 4

↓

$$\frac{2, 1, 3, 4}{4} = M_{gl}(n+1)$$

Measurement values

Output value

Characteristics:

When moving averaging in the optoNCDT 1420 only powers of 2 for the averaging number N are allowed.

Range of values for number of average N is 1 / 2 / 4 / 8 ... 128.

7.4.8.3 Recursive Average

Formula:

$$M_{\text{rek}}(n) = \frac{MV_{(n)} + (N-1) \times M_{\text{rek}}(n-1)}{N}$$

MV = Measurement value,

N = Averaging number,

n = Measurement value index

M_{rek} = Averaging value respectively output value

Mode:

Each new measurement value MV(n) is added, as a weighted value, to the sum of the previous measurement values $M_{\text{rek}}(n-1)$.

Characteristics:

The recursive average permits a high degree of smoothing of the measurement values. However, it requires extremely long transient recovery times for steps in measurement values. The recursive average shows low pass behavior. Range of values for number of average N is 1 ... 32768.

7.4.8.4 Median

The median is generated from a pre-selected number of measurement values.

Mode:

To do so, the incoming measurement values (3, 5, 7 or 9 measurement values) are resorted again after every measurement. The average value is then given as the median. In generating the median in the sensor, 3, 5, 7 or 9 measurement values are taken into account, that is, there is never a median of 1.

Characteristics:

This averaging mode suppresses individual interference pulses. The measurement value curve is not smoothed to a great extent.

Example: Average from five measurement values

... 0 1 2 4 5 1 3 → Sorted measurement values: 1 2 3 4 5 Median_(n) = 3

... 1 2 4 5 1 3 5 → Sorted measurement values: 1 3 4 5 5 Median_(n+1) = 4

7.4.9 Zeroing and Mastering

By zeroing and mastering you can set the measurement value to a set point in the measuring range. The output range is moved thereby. This function makes sense, for example, for several adjacent measuring sensors or in the case of the thickness and planarity measurement.

Master value in mm	<i>Value</i>	<i>Data, for example of the thickness, of a master piece. Value range max. 0 up to + 2 x measuring range</i>
--------------------	--------------	--

Setting masters is used to compensate mechanical tolerances in the measurement setup of the sensors or to adjust the temporal (thermal) changes in the measurement system. The masters measurement, also a known as the calibration measurement, is given a set point.

The value which is given during measurement on the sensor output of the “mastering object“ is the `master value`. The zero-setting is a characteristic of the mastering, because here the master value is 0.

When mastering the sensor’s characteristic is parallel displaced. The displacement of the characteristic curve reduces the usable measurement range of the sensor the further the master value is away from the master position.

Sequence for Mastering / Zeroing:

- ➡ Bring target and sensor in the desired position together.
- ➡ Send the master command.

The master command waits for 2 seconds on the next measurement value and masters it. If no measurement value is received within this time, for example by external triggering, the command returns with the error `E220 Timeout back`.

After the mastering, the sensor gives new measurement values, related to the master value. The non-mastered condition applies by means of a reset with the button `Inactive`.

i Zeroing/Mastering requires that a target is within the measurement range. Zeroing/Mastering has an influence on the digital and the analog output.

An invalid master value, e. g. no peak available, will be acknowledged with the `E602 Master value is out of range error`.

Grey shaded fields require a selection.

Dark-bordered fields require you to specify a value.

7.4.9.1 Zeroing, Mastering with Select Key




Fig. 33 Flow chart for zeroing, mastering (key select)




Fig. 34 Flow chart for the return of zero setting and mastering

- 1) The key `Select` remains without effect since key lock is active.
- 2) The master value is not applied when LED State is red, flash frequency 3 Hz for 2 s.

i The key `Select` is locked according to factory settings after expiry of 5 min. You can unlock the keylock e.g. via the web interface, see Chap. 7.6.3.

The function Zeroing/Mastering can be used several times in succession. Between repetition of the function Zeroing/Mastering a brake of 1 s is necessary. The function Zeroing/Mastering can also be combined with the multifunctional input.

7.4.9.2 Zeroing, Mastering with Hardware Input




Fig. 35 Flow chart for zeroing, mastering (hardware input)




Fig. 36 Flow chart for the return of zero setting and mastering

The function zeroing/mastering can be applied successive in several times. Between repeating the zeroing/mastering function a pause of 1 s is required. The zeroing/mastering function can also be combined with the select key.


1) With red State LED, the master value is not accepted, flashes with 8 Hz for 2 s.


i A pulse on the functional input can be made via pin 9 pigtail resp. via the violet wire on the sensor cable resp. via the PCF1420-x. Details of the hardware input can be found in the electrical connections, see Chap. 5.4.6.

7.4.10 Data Reduction, Output Data Rate

Data reduction	<i>Value</i>	<i>Instructs the sensor, which data are excluded from the output, and thus the amount of transmitted data is reduced.</i>
Reduction applies for	<i>RS422 / Analog</i>	<i>The interfaces, which are provided for the sub-sampling, are to be selected with the checkbox.</i>

You can reduce the measurement output in the sensor if you set the output of every nth measurement value in the web interface or by command. Data reductions causes that only n-th measurement value is output. The other measurement values are rejected. The reduction value n can range from 1 (each measurement value) to 3,000,000. This allows you to adjust slower processes, such as a PLC, to the fast sensor without having to reduce the measuring rate.

 Grey shaded fields require a selection.


 Dark-bordered fields require you to specify a value.

7.5 Outputs

7.5.1 Overview

RS422	Baud rate	9.6 / 19.2 / 56.0 / 115.2 / 230.4 ... / 1000 kBps		Transmission rate with binary data format.
	Output data	Distance / Shutter time / Intensity / Sensor state / Measurement counter / Non-linearized focal point / Time stamp / Video raw signal		The data which are provided for the transmission are to activate with the checkbox.
Analog output	Standard scale			Start of measuring range 4 mA, end of measuring range 20 mA
	Two-point scale	Minimum value	Value	Always 2 points which mark the start and end of a new measuring range are taught. Reversal of the output signal is possible with two-point scaling.
		Maximum value	Value	
Digital output	Inactive			Adjusts the switching characteristic of the digital output (error), see Chap. 5.4.8.
	Full scale error	NPN / PNP / PushPull / PushPullNeg		
Output Interface	Web interface / Analog / RS422			Decides via the used interface for measurement output. A parallel measurement output via multiple channels is not possible. When choosing web interface measurement values are not output via RS422 or current output.

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

7.5.2 Digital Output, RS422

7.5.2.1 Values, Ranges

The digital measuring values are being output as unsigned digital values (raw values). 16 resp. 18 bits per value are being transmitted. Subsequently you can find a compilation of output values and the conversion of the digital value.

Value	Length	Variables	Value range	Formula
Distance (without master- ing)	16 bits	x = digital value	[0; <643] SMR reserve [643; 64877] measuring range [>64877; 65520] EMR reserve	$d \text{ [mm]} = \frac{1}{100} \left(\frac{102}{65520} x - 1 \right) * MR \text{ [mm]}$
		MR = measuring range [mm]	{10/25/50/100/200/500}	
		d = distance [mm]	[-0,01MR; 1,01MR]	
Distance (with master- ing)	18 bits	x = digital value		The output range is also coded with 64235 values at 18 bit and shifted with the master value, see Fig. 37 . The reserves at SMR and EMR are coded with 643 values each. $d \text{ [mm]} = \frac{1}{100} \left(\frac{102}{65520} x - 51 \right) * MR \text{ [mm]}$
		MR = measuring range [mm]	{10/25/50/100/200/500}	
		MP = master position [mm]	[0; MR]	
		MV = master value [mm]	[0; 2MR]	
		d = distance [mm]		
		MV < MP - 0.5MR:	[-0.5MR + MV; MR - MP + MV]	
MV ≥ MP - 0.5MR:	[-MP + MV; MR - MP + MV]			
Exposure time	18 bits	x = digital value	[1; 262143]	$ET \text{ [}\mu\text{s]} = \frac{1}{10} x$
		ET = exposure time [μs]	[0.1; 26214.3]	
Intensity	16 bits	x = digital value	[0; 65472]	$I \text{ [%]} = \frac{25}{16368} x$
		I = intensity [%]	[0; 100]	

Sensor status	18 bits	x = digital value	[0; 242143]	Bit 0 (LSB): peak starts before ROI
		Bit encoding	[0; 1]	Bit 1: peak ends after ROI
				Bit 2: no peak found
		SMR = Start of measuring range		Bit 5: distance before SMR (extended)
		EMR = End of measuring range		Bit 6: distance after EMR (extended)
				Bit 15: measuring value is triggered
				Bit 16, 17: status LED; - 00 – off 10 – red - 01 – green 11 – yellow
Measurement counter	18 bits	x = digital value	[0; 262143]	
Time stamp	2 words, at 16 bit	x = digital value Lo	[0; 65535]	$t \text{ [ms]} = \frac{1}{100} (65536y + x)$
		y = digital value Hi	[0; 65535]	
		t = time stamp [ms]	[0; 11h55m49.67s]	
Non-linearized focus	18 bits	x = digital value	[0; 262143]	$NF \text{ [%]} = \frac{100}{262143} x$
		NF = focus	[0; 100]	
Video raw signal	16 bits	512 pixel	[0; 65535]	


Additional information transmitted in the distance value

Distance value	Description
262075	data amount to big for selected baud rate
262076	no peak available
262077	peak before the measurement range (MR)
262078	peak behind the measurement range (MR)
262080	measurement value can not be calculated
262081	peak is to large
262082	Laser is off


7.5.2.2 Characteristics Digital Output

Measurements are coded with 18 bit, if the based on zero setting or mastering. The master value itself can accept the double measuring range. The examples below show the digital output behavior of an ILD1420-50 with 50 mm measuring range.


Target at 16 % measuring range




Target at 60 % measuring range




Target at 60 % measuring range




➔ Zero setting (master value = 0 mm)



➔ Zero setting (master value = 0 mm)



➔ Set master value 10 mm



Digital minimum reached at 10 % MR




Fig. 37 Digital values without zero setting resp. mastering

➡ Set target at 80 % measuring range (40 mm), set master value 100 mm




Fig. 38 Digital values of an ILD1420-50 with mastering, master value 100 mm

7.5.3 Analog Output Scaling

7.5.3.1 Output Scaling

- Max. output range: 4 mA ... 20 mA
- Output gain ΔI_{OUT} : 16 mA = 100 % MR
- Error value: 3.0 mA ($\pm 10 \mu A$)

The teaching scales the analog output (4 to 20 mA) for a part of the measuring range. This allows you to optimize the resolution for the analog measurement range. Only the current and digital output will be affected by the 2 point calibration. Therefore you define a new start and end for the measurement range. This teaching procedure can be performed live via the select key, the multifunctional input or via the webinterface.

i With a user defined output scaling you can use the digital output, see Chap. 5.4.8, as a programmable limit switch.

The measurement object positions for Teach 1 and Teach 2 have to differ from each other.

The teaching process requires a valid measuring signal. The teaching process is terminated at

- no target,
- target not evaluated,
- to close to the sensor - beyond SMR or
- to far from the sensor - beyond EMR.




Fig. 39 Default characteristic (black), reverse, user defined characteristic (red)

7.5.3.2 Output Scaling with Key Select




Fig. 40 Flow chart for output scaling




Fig. 41 Flow chart for the return of output scaling

If the key `Select` is pressed longer than 10 s or not within the timeframe while doing the return of the output scaling, an error is shown via `State LED`. In this case the `State LED` is blinking red with 8 Hz for 2 s.

7.5.3.3 Output Scaling via Hardware Input

Scaling of the analog output can be made via an impulse at the functional input, pin 9 pigtail resp. via the violet wire on the sensor cable resp. PCF1420-x.




Fig. 42 Flow chart for output scaling




Fig. 43 Flow chart for the return of output scaling

7.5.3.4 Calculation of Measuring Value using Analog Current

Current output (without mastering, without teaching)

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 4)}{16} * MR \text{ [mm]}$
MR = measuring range [mm]	{10/25/50/100/200/500}	
d = distance [mm]	[-0,01MR; 1,01MR]	

Current output (with mastering), reference value is midrange

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 12)}{16} * MR \text{ [mm]}$
MR = measuring range [mm]	{10/25/50/100/200/500}	
MP = master position [mm]	[0; MR]	
d = distance [mm]	for $MP \leq 0.5MR$: [-MP; 0.5MR]	
	for $MP > 0.5MR$: [-0.5MR; MR - MP]	

Current output (with teaching)

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 4)}{16} * n \text{ [mm]} - m \text{ [mm]} $
MR = measuring range [mm]	{10/25/50/100/200/500}	
m, n = teachig area [mm]	[0; MR]	
d = distance [mm]	[m; n]	



Current output (with mastering and teaching)

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 12)}{16} * n \text{ [mm]} - m \text{ [mm]} $
MR = measuring range [mm]	{10/25/50}	
MP = position object [mm]	[0; MR]	
m, n = teaching area [mm]	for MP ≤ 0.5MR: [-MP; 0.5MR] for MP > 0.5MR: [-0,5MR; MR - MP]	
d = distance [mm]	[m; n]	


7.5.3.5 Characteristics Distance Value and Analog Output

The mastering and zero setting function set the analog output on half of the output range independent on the master value, thus 12 mA. The examples below show the current output and the distance value behavior of an ILD1420-50 with 50 mm measuring range.


Target at 16 % measuring range




Target at 60 % measuring range




➡ Zero setting (master value = 0 mm)



➡ Set master value 5 mm




➡ Set master value 10 mm



Analog maximum reached at 66 % MR

Analog minimum reached at 10 % MR

MR = measuring range, SMR = start of measuring range, EMR = end of measuring range



Master point	Master value	Out min	Out max
16 % (8 mm)	0 mm	9.44 mA (-8 mm)	20.0 mA (33 mm)
60 % (30 mm)	10 mm	4.00 mA (-15 mm)	18.40 mA (30 mm)


Fig. 44 Analog output with zero setting resp. mastering

7.5.3.6 Mastering and Teaching Analog Output


Proceed as follows:

1. Mastering or zero setting, menu `signal processing`
2. Teach output, menu `Outputs`

The mastering and zero setting function set the analog output on half of the output range, see Chap. 7.5.3.5.



- ➡ Target at 60 %, set master value 0 mm
- ➡ Set minimum (m) 20 mm and maximum (n) 40 mm



i With $n < m$ generates an inverse characteristic.




Fig. 45 Analog output characteristic after mastering and scaling with an ILD1420-50

7.6 System Settings

7.6.1 General

After programming all the settings are to be stored permanently in a set of parameters. The next time you turn on the sensor they are available again.

7.6.2 Unit, Language

The web interface promotes the units millimeter (mm) and inch when displaying measuring results. You can choose German or English in the web interface. You can change language in the menu bar.





Fig. 46 Language selection in the menu bar

7.6.3 Keylock

The function `keylock` for the key `Select`, see Chap. 5.3 prevents unauthorized / unintended performing of the key functions. Keylock is always activated when user level `User` is chosen. Keylock can only be deactivated in user level `Expert`. If an expert logs in the system, keylock on the sensor is automatically unlocked.

Key lock	<i>Automatic</i>	<i>Range from 1 ... 60 [min]</i>	Value	<i>Keylock starts after expiry of defined time. Clicking the button <code>Refresh</code> prolongs the timeframe until keylock starts.</i>
	<i>Active</i>			<i>The key <code>Select</code> is deactivated independent of the user level.</i>
	<i>Inactive</i>			<i>The key <code>Select</code> is active independent of the user level.</i>

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

7.6.4 Load, Save

All settings to the sensor can be saved permanently in application programs, so called setups.





Fig. 47 Administration of application programs


Administer setups in the sensor, possibilities and procedure			
Save settings	Activate existing setup	Save changes in active setup	Define setup after booting
Menu New setup	Menu Load & Save	Menu bar	Menu Load & Save
<p>➡ Enter the name for the setup into the field <input type="text" value="individueller Setupname"/> , e.g. rubber 1.21 and click the button Save.</p>	<p>➡ Click on the desired setup with the left mouse button, area A.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Load.</p>	<p>➡ Click on the button</p> 	<p>➡ Click on the desired setup with the left mouse button, area A.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Favorite.</p>

Exchange setups with PC/notebook, possibilities	
Save setup on PC	Load setup from PC
Menu Load & Save	Menu Load & Save
<p>➡ Click on the desired setup with the left mouse button, area A.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Export.</p>	<p>➡ Click on Create setup with the left mouse button.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Search.</p> <p>A Windows dialog for file selections opens.</p> <p>➡ Choose the desired file and click on the button Open.</p> <p>➡ Click the button Import in the setup management.</p>

7.6.5 Import, Export

A set of parameters covers current settings, setup(s) and the initial setup when booting the sensor. The menu `Import & Export` enables easy exchange of sets of parameters with a PC/notebook.

Exchange set of parameters with PC/notebook, possibilities	
Save set of parameters on PC	Load set of parameters from PC
Menu <code>Import & Export</code>	Menu <code>Import & Export</code>
<p>➡ Click on the button <code>New set of parameters with the left mouse button..</code></p> <p>The dialog <code>Choose setups for export</code> opens.</p> <p>➡ You arrange a set of parameters by selecting/deselecting the check boxes.</p> <p>➡ Click on the button <code>Transmit file.</code></p> <p>A Windows dialog for file transmission opens.</p> <p>➡ Confirm the dialog with <code>OK.</code></p> <p>The operating system stores the set of parameters in the area <code>Download.</code></p> <p>File name for the following example is <code><...\Downloads\ILD1420_50BASICSETTINGS_Rubber 1.04...\.JSON></code></p>	<p>➡ Click on the button <code>Search.</code></p> <p>A Windows dialog for file selection opens.</p> <p>➡ Choose the desired file and click on the button <code>Open.</code></p> <p>The dialog <code>Choose setups for export</code> opens.</p> <p>➡ You define actions to be made by selecting/deselecting the check boxes.</p> <p>➡ Click on the button <code>Transmit file.</code></p>



A security query, see adjacent figure, helps to avoid that an existing setup is inadvertently overwritten during import.

Options during import:

Overwrite existing setups (with the same name)
 Apply settings of the imported boot setup

7.6.6 Access Authorization


The assignment of a password prevents unauthorized changing of settings on the sensor. When delivered, the password protection is not enabled. The sensor operates in the user level `Professional`. The password protection should be enabled after configuration of the sensor. The default password for the expert level is 000.

i The default password or a user-defined password is not changed by a software update. The professional password is independent of the setup and is therefore not together loaded or saved with the setup.

The following functions are available for the user:

	User	Professional
Password required	no	yes
Viewing settings, signal processing, outputs, system settings	yes	yes
Changing settings, signal processing, outputs, system settings	no	yes
Changing password	no	yes
Changing between the measurement and video signal chart types	no	yes
Scaling diagrams	yes	yes
Setting factory setting	no	yes

Fig. 48 Rights in the user hierarchy



Type in the default password 000 or a user-defined password in the Password field and confirm with Login.

Change with a click on the Logout button in the mode user.

Fig. 49 Change in the professional user level

The user management allows you to assign a custom password in the `Professional` mode.


Password	<i>Value</i>	<i>Case-sensitive rules are observed for all passwords. Numbers are allowed. Special characters are not allowed. Maximum length is set to 31 characters.</i>
User level when restarting	<i>User / Professional</i>	<i>Specifies the user level, with which the sensor starts after the re-starting. For this purpose, MICRO-EPSILON recommends the selection <code>user</code>.</i>

After configuration of the sensor the password protection is to be activated. Please note the password for later reference.

7.6.7 Sensor Reset

Sensor reset	Sensor settings	<i>Button</i>	<i>Settings for baud rate, language, unit, keylock and echo mode are deleted and the default parameters are loaded.</i>
	Measurement settings	<i>Button</i>	<i>Settings for measuring rate, trigger, evaluation range, peak selection, error handling, averaging, zeroing/mastering, data reduction and the setups are deleted. The 1st preset will be loaded.</i>
	Reset all	<i>Button</i>	<i>When clicking this button settings for sensor, measuring preferences, access authorization, password and the setups are deleted. The 1st preset will be loaded.</i>
	Restart sensor	<i>Button</i>	<i>When clicking this button the sensor is rebooted with the settings from the setup Favorite, see Chap. 7.6.4.</i>

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

8. Digital Interfaces RS422

8.1 Preliminary Remarks

The interface RS422 has a maximum baud rate of 1 MBaud. The factory-set baud rate is 921.6 kBaud. The maximum measuring rate is 4 kHz.

Data format: Measurement values in binary format, commands as an ASCII string.

Interface parameter: 8 Data bits, no parity, one stop bit (8N1).

i Disconnect or connect the D-sub connection between RS422 and USB converter when the sensor is disconnected from power supply only.

8.2 Measurement Data Format

16¹ resp. 18 bits are transmitted per output value, see Chap. 7.5.2. An output value is divided into three bytes that differ in the two most significant bits. The transmission of additional output values is optional.

Output value 1 / additional:

L-Byte	0	0	D5	D4	D3	D2	D1	D0
M-Byte	0	1	D11	D10	D9	D8	D7	D6
H-Byte	1	0 ²	0 ³	0 ³	D15	D14	D13	D12

Output sequence: L-Byte, M-Byte, H-Byte.

1, 3) Error values are coded with 18 Bit.

2) To decide between the 1st output value and additional output values, bit 7 in the H-Byte is set to 1. Bit 7 in the H-Byte is set to 0 for the 1st output value. This simultaneously represents the identifier of a new block. Depending on the measuring rate, baud rate and output data rate output all data can be output in one block. If data output is not possible, a run-time error will be output. Use the command GETOUTINFO_RS422 to query for data selection and output sequence.

8.3 Conversion of the Binary Data Format

For conversion purposes the H-Byte, M-Byte and L-Byte must be identified on the basis of the two first bits (flag bits), the flag bits deleted and the remaining bits compiled into a 16 or 18 bit data word.

Result of conversion:

D17	D16	D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0
-----	-----	-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----

Conversion must be done in the application program. D16 and D17 are among others used for interpretation of error codes or e.g. for the measurement counter.

- **i** The sensor continues to deliver measurement values to the RS422 output even while communicating with the sensor.

For the data transmission with a PC the MICRO-EPSILON IF2008 PCI BUS interface card is suitable. This can be connected to the sensor via the PC2300-x/IF2008 interface cable, which is also available as an option. The IF2008 combines the three bytes for the data word and saves them in the FIFO. The 18 bits are used for measurement values and error values. As standard, the IF2008 interface card is suitable for connecting two or (via a Y intermediate cable available as an option) up to four sensors plus two additional incremental encoders. For further information, please refer to the descriptions of the IF2008 interface card and associated MEDAQlib driver program.

You will find the latest program routine at: www.micro-epsilon.com/link/software/medaqlib.

9. Cleaning

Cleaning of the protective screens is recommended periodically.

Dry Cleaning

Therefore an optics anti-static brush is suitable or bleeding the screen with dehumidified, clean and oil-free compressed air.

Wet Cleaning

For cleaning the protective screen use a clean, soft, lint-free cloth or lens cleaning paper with pure alcohol (isopropyl).

Never use standard glass cleaner or other cleaning agents.

10. Software Support with MEDAQLib

MEDAQLib offers you a documented driver DLL. Therewith you embed optoNCDT laser sensors, in combination with

- the 1-way converter IF2001/USB or
- the 4-way converter IF2004/USB and connection cable PCF1420-x/IF2008 (IF2008-Y) or
- the PCI interface card IF 2008 and connection cable PCF1420-x/IF2008 and IF2008-Y-adapter cable

into an existing or a customized PC software.

MEDAQLib

- contains a DLL, which can be imported into C, C++, VB, Delphi and many additional programs,
- makes data conversion for you,
- works independent of the used interface type,
- features by identical functions for the communication (commands),
- provides a consistent transmission format for all MICRO-EPSILON sensors.

For C/C++ programmers MEDAQLib contains an additional header file and a library file. You will find the latest driver / program routine at:

www.micro-epsilon.de/download

www.micro-epsilon.de/link/software/medaqlib

11. Warranty

All components of the device have been checked and tested for perfect function in the factory. In the unlikely event that errors should occur despite our thorough quality control, this should be reported immediately to MICRO-EPSILON.

The warranty period lasts 12 months following the day of shipment. Defective parts, except wear parts, will be repaired or replaced free of charge within this period if you return the device free of cost to MICRO-EPSILON. This warranty does not apply to damage resulting from abuse of the equipment and devices, from forceful handling or installation of the devices or from repair or modifications performed by third parties.

No other claims, except as warranted, are accepted. The terms of the purchasing contract apply in full. MICRO-EPSILON will specifically not be responsible for eventual consequential damages. MICRO-EPSILON always strives to supply the customers with the finest and most advanced equipment. Development and refinement is therefore performed continuously and the right to design changes without prior notice is accordingly reserved. For translations in other languages, the data and statements in the German language operation manual are to be taken as authoritative.

12. Decommissioning, Disposal

 Disconnect the power supply and output cable on the sensor.

Incorrect disposal may cause harm to the environment.

Dispose of the device, its components and accessories, as well as the packaging materials in compliance with the applicable country-specific waste treatment and disposal regulations of the region of use.

13. Service, Repair

In the event of a defect on the sensor or the sensor cable:

- If possible, save the current sensor settings in a parameter set, see Chap. 7.6.4, in order to load again the settings back into the sensor after the repair.
- Please send us the effected parts for repair or exchange.

In the case of faults the cause of which is not clearly identifiable, the whole measuring system must be sent back to

MICRO-EPSILON Optronic GmbH
Lessingstraße 14

01465 Langebrück / Germany

Tel. +49 (0) 35201 / 729-0

Fax +49 (0) 35201 / 729-90


optronic@micro-epsilon.de

www.micro-epsilon.com

Appendix

A 1 Optional Accessories

IF2001/USB



Converter RS422 to USB, type IF2001/USB, useable for cable PCF1420-x/I or PCF1420-x/U, inclusive driver, connections: 1 × female connector 10-pin (cable clamp) type Würth 691361100010, 1x female connector 6-pin (cable clamp) type Würth 691361100006

IF2004/USB




4 channel converter RS422 to USB useable for cable PCF1420-x/IF2008 (IF2008-Y), inclusive driver, connections: 2 × Sub-D, 1 × terminal block

PS2020



Power supply for mounting on DIN rail, input 230 VAC, output 24 VDC/2.5 A

IF2008



The IF2008 interface card enables the synchronous capture of 4 digital sensor signals series optoNCDT 1420 or others or 2 encoders. In combination with IF2008E a total of 6 digital signals, 2 encoder, 2 analog signals and 8 I/O signals can be acquired synchronously.

IF2008-Y adapter
cable



Used to connect two sensors with interface
cable PC2300-x/IF2008 to a port of the IF2008.

A 2 Factory Setting

Password	„000“
Measuring rate	2 kHz
Measuring range	100 % FSO: I = 20 mA , digital 64877
	0 % FSO: I = 4 mA, digital 643
Peak selection	Highest peak
Error handling	Error output, no measurement

Measurement averaging	Median 9
Output	Analog current
RS422	921.6 kBaud
Trigger mode	No trigger
Language	German




Fig. 50 Flow chart to start a sensor with factory setting

- t_0 : power supply is on
 - $t_1 \dots t_3$: both LEDs signalize the start sequence (red-yellow-green for 1 sec. each)
 - t_2 : key is pressed during start sequence ($t_1 \dots t_3$)
 - t_4 : key is released while the LED State is flashing red
- $\Delta t = t_4 - t_2$; Δt (key press period) must be at least 10 sec., max. 15 sec.

A 3 ASCII Communication with Sensor

A 3.1 General

The ASCII commands can be sent to the sensor via the RS422 interface. All commands, inputs and error messages are effected in English.

One command always consists of a command name and zero or several parameters, which are separated by blanks and are completed with LF. If blanks are used in parameters, the parameter must be set in quotation marks.

Example: Switch on the output via RS422

OUTPUT RS422 ←↵

Advice: ←↵ must include LF, but may also be CR LF.

Declaration: LF Line feed (line feed, hex 0A)

CR Carriage return (carriage return, hex 0D)

←↵ Enter (depending on the system System hex 0A or hex 0D0A)

The currently set parameter value is returned, if a command is activated without parameters.

The input formats are:

```
<Command name> <Parameter1> [<Parameter2> [...]]
```

```
<Command name> <Parameter1> <Parameter2> ... <Parameter...>
```

or a combination thereof.

Parameters in []-brackets are optional and require the input of the parameter standing in front. Sequent parameters without []-brackets are to input compulsory, that is, it must not be omitted a parameter.

Alternative inputs of parameter values are displayed separately by „|“, for example the values „a“, „b“ or „c“ can be set for „a|b|c“. Parameter values in <> brackets are selectable from a value range.

Declarations on format:

„a b“	Value of the parameter can be set to the value “a” or “b”.
„ P1 P2“	It requires that both parameters “P1” and “P2” are set.
„ P1 [P2 [P3]]“	The parameters “P1”, “P2” and “P3” can be set, whereby “P2” may only be set, if “P1” is set and “P3” only if “P1” and “P2” are set.

„<a>“	The value of the parameter lies in a value range of “... to ...“, see parameter description.
-------	--

Parameter values without peak brackets can only assume discrete values, see parameter description.

Parantheses are to be understood as a grouping, that is, for a better articulation „P1 P2 | P3“ is written as „(P1 P2)|P3“.

Example without []:

„PASSWD <Old password> <New password> <New password>“

- To change the password, all three parameters are to be input.

The output format is:

<Command name> <Parameter1> [<Parameter2> [...]]

The reply can be used again as command for the parameter setting without changes. Optional parameters are only returned, if the returning is necessary. For example, the activated output values are returned by command Data selection additional values. After processing a command always a return and a prompt (“->“) is returned. In the case of an error an error message is before the prompt, that begins with „Exxx“, where xxx is a unique error number. Also warnings („Wxxx“) can be output instead of error messages.

These are analogous to the error messages. In case of warnings the command is executed.

The replies to the commands GETINFO and PRINT are useful for support requests to the sensor, because they contain sensor settings.

A 3.2 Overview Commands

Group	Chapter	Command	Short description
General			
	Chap. A 3.3.1	HELP	Help on commands
	Chap. A 3.3.2	GETINFO	Request sensor information
	Chap. A 3.3.3	LANGUAGE	Determine language of website
	Chap. A 3.3.4	RESET	Reboot sensor
	Chap. A 3.3.5	RESETCNT	Reset counter
	Chap. A 3.3.6	ECHO	Switching the command reply, ASCII interface
	Chap. A 3.3.7	PRINT	Output of all sensor settings
User level			
	Chap. A 3.3.8.1	LOGIN	Change of user level
	Chap. A 3.3.8.2	LOGOUT	Change to user in the user level
	Chap. A 3.3.8.3	GETUSERLEVEL	User level request
	Chap. A 3.3.8.4	STDUSER	Setting the standard user
	Chap. A 3.3.8.5	PASSWD	Change password
Triggering			
	Chap. A 3.3.9.1	TRIGGER	Selection of trigger mode
	Chap. A 3.3.9.2	TRIGGERAT	Effect of the trigger input
	Chap. A 3.3.9.3	MFILEVEL	Selection of level for multifunctional input
	Chap. A 3.3.9.4	TRIGGERCOUNT	Number of measurement values displayed
	Chap. A 3.3.9.5	TRIGGERSW	Software - trigger pulse

Interfaces		
Chap. A 3.3.10.1	BAUDRATE	RS422 setting
Chap. A 3.3.10.2	UNIT	Selection of measuring unit web interface
Chap. A 3.3.10.3	MFIFUNC	Selection of function multifunctional input
Chap. A 3.3.10.4	ERROROUT1	Activate digital output
Chap. A 3.3.10.5	ERRORLEVELOUT1	Output level digital output
Chap. A 3.3.10.6	ERRORLIMIT	Limit to activate digital output
Chap. A 3.3.10.7	ERRORHYSTERESIS	Stable digital output
Chap. A 3.3.10.8	ERROROUTHOLD	Minimum duration active digital output
Handling of setups		
Chap. A 3.3.11.1	IMPORT	Load parameter
Chap. A 3.3.11.2	EXPORT	Export sensor settings
Chap. A 3.3.11.3	MEASSETTINGS	Load/save measurement settings
Chap. A 3.3.11.4	BASICSETTINGS	Load/save device settings
Chap. A 3.3.11.5	SETDEFAULT	Factory settings
Scaling of analog output		
Chap. A 3.3.12	ANALOGSCALE	Scaling analog output
Key function		
Chap. A 3.3.13.1	KEYFUNC	Selection of key function
Chap. A 3.3.13.2	KEYLOC	Selection of keylock

Measurement		
General		
Chap. A 3.4.1	TARGETMODE	Choice of measurement algorithms
Chap. A 3.4.2	MEASPEAK	Choice of the peak in the video signal
Chap. A 3.4.3	MEASRATE	Selection of measuring rate
Chap. A 3.4.4	LASERPOW	Selection of laser power
Chap. A 3.4.5	ROI	Masking the region of interest
Measurement Value Processing		
Chap. A 3.4.6.1	AVERAGE	Selection of measurement averaging
Chap. A 3.4.6.2	MASTERMV	Mastering / Zeroing
Data Output		
General		
Chap. A 3.5.1	OUTPUT	Selection measuring value output
Chap. A 3.5.2	OUTREDUCEDEVICE	Selection of interface for data reduction
Chap. A 3.5.3	OUTREDUCECOUNT	Reduces measurement value output
Chap. A 3.5.4	OUTHOLD	Setting of error processing
Select measurement values to be output		
Chap. A 3.5.5.1	GETOIUTINFO_RS422	Request data selection
Chap. A 3.5.5.2	OUTADD_RS422	Selection of additional values
Chap. A 3.5.5.3	OUTVIDEO_RS422	Stop video output

A 3.3 General Commands**A 3.3.1 HELP**

```
HELP [<Command>]
```

Issues a help for every command. If no command is specified, a general help is output.

A 3.3.2 GETINFO, Sensor Information

```
GETINFO
```

Request of sensor information. Output see example below:

```
->GETINFO
Name:                ILD1420-10           //Model name sensor, sensor series
Serial:              15030002            //Serial number
Option:              000                 //Option number of sensor
Article:             4120212            //Article number of sensor
Cable head:         Wire
Measuring range:    10.00mm             //Measuring range of sensor
Version:            001.010             //Version of software
Hardware-rev:       00
Boot-version:       001.000
->
```

A 3.3.3 LANGUAGE, Website

```
LANGUAGE DE | EN | CN
```

Determines the language for the web interface.

- DE: set language to German
- EN: set language to English
- CN: set language to Chinese

The chosen language setting applies to the website.

A 3.3.4 RESET, Boot Sensor

RESET

The sensor is rebooted.

A 3.3.5 RESETCNT, Reset Counter

RESETCNT [TIMESTAMP] [MEASCNT]

Sets back internal counters in the sensor.

- TIMESTAMP: sets back timestamp
- MEASCNT: sets back measurement counter

A 3.3.6 ECHO, Switching the Command Reply, ASCII Interface

ECHO ON|OFF

Setting the command reply with a ASCII command:

- ON: command reply on, for example <Kdo> ok (or notice of error)
->
- OFF: command reply off, for example ->

A 3.3.7 PRINT, Sensor Settings

PRINT

Print serves the output of all sensor settings.

Example of an answer:

```
GETUSERLEVEL PROFESSIONAL      OUTPUT ANALOG
STDUSER PROFESSIONAL          OUTREDUCEDEVICE NONE
BAUDRATE 921600              OUTREDUCECOUNT 2
UNIT MM                       OUTVIDEO_RS422 NONE
LANGUAGE DE                   OUTADD_RS422 NONE
MFIFUNC NONE                  GETOUTINFO_RS422 DIST1
MFILELEVEL HTL_HIGH          OUTHOLD NONE
KEYFUNC NONE                  ERROROUT1 DIST
KEYLOCK AUTO 5 (IS_ACTIVE)    ERRORLEVELOUT1 NPN
TARGETMODE STANDARD          ANALOGSCALE STANDARD
MEASRATE 2.000
MEASPEAK DISTA                ->
ROI 0 511
AVERAGE MEDIAN 9
TRIGGERAT INPUT
TRIGGER NONE
TRIGGERCOUNT INFINITE
LASERPOW FULL
MASTERMV NONE
```

A 3.3.8 User Level

A 3.3.8.1 LOGIN, Change of the User Level

```
LOGIN <Password>
```

Enter the password to change user level. The following user levels are available:

- USER (standard user): “read-only” access to all elements and graphical display of output values of web surface
- PROFESSIONAL (expert): “read-only” and “write” access to all elements

A 3.3.8.2 LOGOUT, Change into User Level

```
LOGOUT
```

Set user level to USER.

A 3.3.8.3 GETUSERLEVEL, User Level Request

```
GETUSERLEVEL
```

Request current user level

A 3.3.8.4 STDUSER, Set Standard User

```
STDUSER USER|PROFESSIONAL
```

Set standard user who is automatically logged in after system start. Standard user does not change with LOGOUT which means login as standard user is done automatically after the command RESET or power supply of sensor is switched on.

A 3.3.8.5 PASSWD, Change Password

```
PASSWD <Old Password> <New password> <New password>
```

Change password for user level PROFESSIONAL.

Type in the old password followed by the new password (2x). In case the new password is not typed in correctly, an error message is will be displayed. Password may only contain letters from A to Z, no numbers 0 to 9. Watch upper and lower case lettering. The maximum length is limited to 31 characters.

A 3.3.9 Triggering

The multifunctional input also serves as trigger input.

A 3.3.9.1 TRIGGER, Selection

```
TRIGGER NONE | EDGE | PULSE | SOFTWARE
```

- NONE: no triggering
- PULSE: level triggering
- EDGE: edge triggering
- SOFTWARE: software triggering

A 3.3.9.2 TRIGGERAT, Effect of the Trigger Input

```
TRIGGERAT INPUT | OUTPUT
```

- INPUT: triggers the measurement value recording. Measurement values immediately before the trigger event are not included when calculating the mean value. Instead, older values are used which were output during previous trigger events.
- OUTPUT: triggers the measurement value output. Measurement values immediately before the trigger event are included when calculating the mean.

A 3.3.9.3 MFILELEVEL, Input Pulse Multifunctional Input

```
MFILELEVEL HTL_HIGH | HTL_LOW
```

Selection of switching or trigger level for the multifunctional input.

- HTL_HIGH: high active (edge triggering: rising edge, pulse triggering: high active)
- HTL_LOW: low active (edge triggering: falling edge, pulse triggering: low active)

A 3.3.9.4 TRIGGERCOUNT, Number of Displayed Measurement Values

```
TRIGGERCOUNT NONE | INFINITE | <n>
```

```
<1...16382>
```

Number of displayed measurement values while triggering

- NONE: stop triggering and start continuous output
- INFINITE: start continuous output after first trigger impulse
- <n>: number of displayed measurement values after each trigger impulse n = 1 ... 16382

A 3.3.9.5 TRIGGERSW, Software Trigger Pulse

TRIGGERSW

Creates a trigger pulse. Error message is displayed if "SOFTWARE" is not selected in trigger selection.

A 3.3.10 Interfaces**A 3.3.10.1 BAUDRATE, RS422**

```
BAUDRATE 9600|19200|56000|115200|128000|230400|256000|460800|691200|921600|
1000000
```

Set the baud rate for the RS422 interface.

A 3.3.10.2 UNIT, Web Interface

UNIT MM|INCH

Change the measurement display on the websites. The command has no effect on the ASCII interface.

- MM representation in mm
- INCH representation in customs

A 3.3.10.3 MFIFUNC, Function Selection Multifunctional Input

MFIFUNC NONE | MASTER | TEACH | TRIGGER

Choose function of the multifunctional input.

- NONE: multifunctional input has no function
- MASTER: multifunctional input is master impulse input
- TEACH: multifunctional input is teach input for analog output
- TRIGGER: multifunctional input is trigger input

A 3.3.10.4 ERROROUT1, Activate Digital Output

ERROROUT1 NONE|DIST|TEACH|LI1

Choose error signal of the digital output.

- NONE: error ourput deactivated
- DIST: no peak found or beyond measuring range (out of range)
- TEACH: Distance is out of scaled analog range
- LI1: Distance is greater than the limit value (ERRORLIMIT)

A 3.3.10.5 ERRORLEVELOUT1, Output Level Digital Output

`ERRORLEVELOUT1 NPN|PNP|PUSHPULL|PUSHPULLNEG`

Choice of output level for ERROROUT1.

- NPN: digital output is active in case of an error
- PNP: digital output is active in case of an error
- PUSHPULL: digital output with high level in case of an error
- PUSHPULLNEG: digital output with low level in case of an error

Wiring of digital output ERROR1, see Chap. 5.4.8.

A 3.3.10.6 ERRORLIMIT

`ERRORLIMIT DIST1 <upper threshold>`

Digital output is activated, if the defined value for a measurement is exceeded.

Range: 0 ... 2 * measuring range [mm].

A 3.3.10.7 ERRORHYSTERESIS

`ERRORHYSTERESIS <hysteresis>`

Digital output is deactivated, if the defined value for a measurement falls below the limit value.

Range: 0 ... 2 * measuring range [mm].

A 3.3.10.8 ERROROUTHOLD

`ERROROUTHOLD <hold period>`

Indicates in ms how long the digital output must be active at least when the limit value is exceeded. This time period starts when the limit value is exceeded. Range: 0 ... 1000 [ms].

A 3.3.11 Handling of Setups

A 3.3.11.1 IMPORT

```
IMPORT [FORCE] [APPLY] <Data>
```

Import of data in JSON format ¹ to the sensor.

First, the import command returns a prompt (->). Afterwards, data can be sent.

After importing a prompt (->) is returned.

- FORCE: overwriting of measurement settings (= MEASSETTINGS) with the same name (otherwise an error message is returned when using the same name). When importing all measurement settings or device settings (= BASICSETTINGS) FORCE must always be stated.
- APPLY: applying the settings after importing / reading of initial settings.

A 3.3.11.2 EXPORT

```
EXPORT ALL | MEASSETTINGS_ALL | (MEASSETTINGS <SetupName>) | BASICSETTINGS
```

Exporting sensor settings. As a response data is transmitted in JSON format. Finally a prompt occurs.

A 3.3.11.3 MEASSETTINGS, Load / Save Measurement Settings

```
MEASSETTINGS <Subcommands> [Name]
```

Settings of the measurement task.

Loads proprietary presets and user-specific settings from the sensor or stores user-specific setups in the sensor.

Subcommands:

- CURRENT: Output of the name of current measurement setting
- PRESETLIST: Listing of all existing presets (names): „Standard“, „Multi-Surface“, „Light Penetration“.
- LIST: Listing of all saved measurement settings (names) “Name1” “Name2” “...”.
- READ <Name>: Loads a preset or a measurement setting from the sensor.
- STORE <Name>: Saves the current measurement setting in the sensor.
- DELETE <Name>: Deletes a measurement setting
- RENAME <NameOld> <NameNew> [FORCE]: Renaming a measurement setting. An existing measurement setting can be overwritten with FORCE.
- INITIAL <name> | AUTO: Loads a named or last saved measurement setting at the start of the sensor. Presets can not be specified.

1) JSON format, see https://de.wikipedia.org/wiki/JavaScript_Object_Notation

- PRESETMODE: Returns the set signal quality
- PRESETMODE <Mode>: Setting the signal quality. Setting the signal quality is possible only, if a preset was loaded.
 - <mode> = STATIC|BALANCED|DYNAMIC|NOAVERAGING|NONE

A 3.3.11.4 BASICSETTINGS, Load / Save Device Settings

BASICSETTINGS READ | STORE

- READ: Loads the stored device settings from the sensor.
- STORE: Saves the current device settings in the sensor.

A 3.3.11.5 SETDEFAULT, Default Settings

SETDEFAULT ALL | MEASSETTINGS | BASICSETTINGS

Sets sensor back to default settings.

- ALL: Measurement and device settings are being deleted. The standard preset for the measurement setting resp. the the default parameter for the device settings are being loaded.
- MEASSETTINGS: Measurement settings are being deleted and the standard preset is being loaded.
- BASICSETTINGS: Device settings are being deleted and the default parameters are being loaded.

A 3.3.12 ANALOGSCALE, Scaling the Analog Output

ANALOGSCALE STANDARD| (TWOPOINT <Minimum value> <Maximum value>)

Setting the two point scaling of the analog output.

- STANDARD: using the measuring range of the sensor
- TWOPOINT: two point scaling within the analog range (4 - 20 mA)
 - Minimum value: measurement value in mm which is matched to the lower analog value (4 mA)
 - Maximum value: measurement value in mm which is matched to the upper analog value (20 mA)

i The minimum value (in mm) can be higher than the maximum value (in mm), see Chap. 7.5.3.

A 3.3.13 Key Function

A 3.3.13.1 KEYFUNC, Choose Key Function

```
KEYFUNC NONE | MASTER | TEACH
```

Choice of key function.

- NONE: key has no function
- MASTER: key is used for mastering
- TEACH: key is used for teaching

A 3.3.13.2 KEYLOCK, Set Keylock

```
KEYLOCK NONE|ACTIVE|AUTO <time>
```

Choice of keylock.

- NONE: key works permanently, no keylock
- ACTIVE: keylock is activated right after reboot
- AUTO: keylock is only activated <time> minutes after reboot

A 3.4 Measurement

A 3.4.1 TARGETMODE, Measurement Mode

```
TARGETMODE STANDARD|MULTISURFACE|PENETRATION 1
```

Choice of material dependent presets, see Chap. 7.4.2.

- STANDARD: suitable for materials, e.g. made of ceramics, metal, plastics or wood
- MULTISURFACE: suitable for materials with changing surfaces, e.g. PCB or hybrid materials
- PENETRATION: suitable for materials with strong penetration depth of the laser light

A 3.4.2 MEASPEAK, Choice of the Peak in the Video Signal

```
MEASPEAK DISTA|DIST1|DISTL
```

- DISTA: output of peak with highest amplitude (standard)
- DIST1: output of first peak
- DISTL: output of last peak

A 3.4.3 MEASRATE, Measuring Rate

```
MEASRATE 0.25|0.5|1|2|4
```

Choice of measuring rate in kHz.

A 3.4.4 LASERPOW, Laser Power

```
LASERPOW FULL|OFF
```

- FULL: laser power is set to 100 %
- OFF: laser is switched off

1) Available for the sensor models ILD1420-10/25/50.

A 3.4.5 ROI, Video Signal, Masking the Region of Interest (ROI)

```
ROI <Start> <End>
```

Set “region of interest”. ROI for start and end is between 0 and 511. “Start” value is smaller than “End” value. For sensors with 500 mm measuring range this is a individually value < 511.

A 3.4.6 Measurement Value Processing

A 3.4.6.1 AVERAGE, Measurement Value

```
AVERAGE NONE|(MOVING|RECURSIVE|MEDIAN [<Averaging depth>])
```

Averaging affects the displacement value to be output.

- MOVING: Moving averaging value (averaging depth 2, 4, 8, 16, 32, 64 and 128 possible)
- RECURSIVE: Recursive averaging value (averaging depth 1 up to 32768 possible)
- MEDIAN: Median (averaging depth 3, 5, 7 and 9 possible)

A 3.4.6.2 MASTERMV, Mastering / Zeroing

MASTERMV NONE | MASTER <MV>

- NONE: completes mastering
- MASTER: sets the current measurement value as a master value
- MV: master value in millimeters; $MV = (0 \dots 2) * \text{measuring range}$, i.e. master value must be within measuring range

In case of master value is 0, the mastering has the same functionality as the zeroing. The parameter MV always operates independently from an input as zeroing during mastering the analog output.

The master command awaits the next measurement value, a maximum of 2 seconds, and masters it. If no measurement value is received within this time, for example, by external triggering, the command returns with the error "E104 Timeout".

The master value is processed with six decimal places.

Note that the output value is limited to 18 bits.

A 3.5 Data Output

A 3.5.1 OUTPUT, Selection of Measurement Value Output

OUTPUT NONE | RS422 | ANALOG

- NONE: no measurement value
- RS422: output of measurement value via RS422
- ANALOG: analog output of measurement values

A 3.5.2 OUTREDUCEDEVICE, Output Reduction of Measurement Value Output

OUTREDUCEDEVICE NONE | ([RS422] [ANALOG])

Selection of interface for data reduction.

- NONE: no data reduction
- RS422: data reduction for RS422
- ANALOG: data reduction for analog output

A 3.5.3 OUTREDUCECOUNT, Output Data Rate

```
OUTREDUCECOUNT <n>
```

Reduces measurement value output of the chosen interfaces.

- 1: outputs each measurement value
- 2 ... 3000000: output of each n-th measurement value

A 3.5.4 OUTHOLD, Error Processing

```
OUTHOLD NONE | INFINITE | <n>
```

Setting the behavior of the measurement value output in case of error.

- NONE: no holding of the last measurement value, output of error value
 - INFINITE: infinite holding of the last measurement value
 - <n>: holding of the last measurement value on the number of measurement cycles; then an error value is output
- n = (1 ... 1024)

A 3.5.5 Selection of Measurement Values to be Output**A 3.5.5.1 GETOUTINFO_RS422, Request Data Selection**

```
GETOUTINFO_RS422
```

The command lists all selected output data for the RS422 interface. The sequence shown corresponds to the output sequence.

A 3.5.5.2 OUTADD_RS422, Selection of Data Additional Values

```
OUTADD_RS422 NONE | ([SHUTTER] [COUNTER] [TIMESTAMP] [INTENSITY] [STATE]  
[DIST_RAW])
```

Selection of additional values to be transmitted.

- NONE: no output of additional values
- SHUTTER: output of exposure time
- COUNTER: output of measurement value counter
- TIMESTAMP: output of timestamp
- INTENSITY: output of intensity parallel to each distance value
- STATE: output of status word
- DIST_RAW: output of uncalibrated distance value (raw value)

A 3.5.5.3 OUTVIDEO_RS422, Adjust Video Output

OUTVIDEO_RS422 NONE|VIDEO_RAW

Defines the data to be transmitted at a video image transmission via RS422.

- NONE: no video images
- VIDEO_RAW: output of uncorrected video signal (raw signal)

A 3.6 Example Command Sequence During Selection of Measurement Value

Command	Content
MEASPEAK	Peak selection for displacement measurement
MEASRATE	Measuring rate (under consideration of reflectivity and movement of the target)
AVERAGE	Averaging of the measurement value (under consideration of reflectivity, structure and movement of the target)
OUTPUT	Selection of the output channel
OUTREDUCEDEVICE	Reduction of the output data rate (under consideration of the chosen output channel, its settings and the processing range of the target system)
OUTREDUCECOUNT	
OUTHOLD	Output characteristic during measurement errors
OUTADD_RS422	Selection of the additional values to be output for RS422 interface
BAUDRATE	Baud rate settings RS422 interface

A 3.7 Error Messages

If an error occurs with a command, the error message is listed.

Error message	Description
E100 Internal error	Internal error code
E104 Timeout	Timeout while mastering.
E200 I/O operation failed	Cannot write data to the output channel.
E202 Access denied	Access denied: Login as expert is necessary.
E204 Received unsupported character	An unsupported character was received
E210 Unknown command	Unknown command rights to small to read).
E214 Entered command is too long to be processed	The entered command with the parameters is too long (greater than 255 bytes).
E220 Timeout, command aborted	Timeout during mastering.
E232 Wrong parameter count	Too high or too small number of parameters.
E234 Wrong or unknown parameter type	A transmitted parameter has a wrong type or a wrong number of parameters were transmitted.
E236 Value is out of range or the format is invalid	The parameter value is out of range of the value range.
E262 Active signal transmission, please stop before	A measurement value transmission is active. Stop the data transmission in order to execute the command.
E320 Wrong info-data of the update	For update only: the header of update data contains an error.
E321 Update file is too large	For update only: update data is too large.
E322 Error during data transmission of the update	For update only: error during update data transmission.
E323 Timeout during the update	For update only: Timeout during the transmission of update data.
E331 Validation of import file failed	The import file is not valid.

E332 Error during import	Error during processing the import data
E333 No overwrite during import allowed	No overwrite of measurement and device settings allowed through import, set the checkbox.
E350 The new passwords are not identical	Password and verification password do not match.
E360 Name already exists or not allowed	The measurement setting name already exists or is not allowed.
E361 Name begins or ends with spaces or is empty	Name for the measurement setting begins or ends with spaces or is empty.
E362 Storage region is full	Number of storable measurement settings is reached.
E363 Setting name not found	Name of the measurement setting to be loaded not found
E364 Setting is invalid	Measurement resp. device setting is invalid
E600 ROI begin is greater than ROI end	ROI begin is greater than ROI end.
E602 Master value is out of range	Master value is out of valid range
E616 Software triggering is not active	Software triggering is not active.

Warning	Description
W320 The measuring output has been adapted automatically.	The measuring output has been adapted automatically.
W570 The input has been adapted automatically to a limited range.	---

A 4 Control Menu**A 4.1 Tab Home**

Measurement task	Presets	Standard	Suitable for materials made of ceramics, metal or filled plastics
		Changing surface ¹	Suitable for e.g. PCB or hybrid materials
		Material with penetration ¹	Suitable for plastics (POM, Teflon), materials with strong penetration of the laser
	Setups	Setup 1 ... Setup 8	Setups contain user-specific measurement settings. Unlike the presets they can be changed anytime.
Signal quality		Static / balanced / dynamic	The signal quality affects averaging of measurement values.

A 4.2 Tab Settings**A 4.2.1 Inputs**


Laser on/off	On / Off		Laser on/off is only effective when pin 8 is connected to GND.
Multifunctional input	Zeroing (Mastering)	High / Low	Sets the function of the digital input. The trigger affects recording and output of a measurement value. Zeroing/Mastering sets the current measurement value to the entered master value. Teaching scales the analog output. HTL is defined as active input level.
	Trigger In	High / Low	
	Teaching		
	Inactive		
Key function	Zeroing (Mastering)		Sets the function of the sensor key. Inactive means keylock.
	Teaching		
	Inactive		

1) Available for the sensor models ILD1420-10/25/50.

A 4.2.2 Signal Processing

Measurement task	<i>Standard</i>			<i>Suitable for materials made of ceramics, metal or filled plastics</i>
	<i>Multi-surface</i> ¹			<i>Suitable for e.g. Printed circuit boards (PCB) or hybrid materials</i>
	<i>Light penetration</i> ¹			<i>Suitable for plastics (POM, Teflon), materials with strong penetration of the laser</i>
Measuring rates	250 Hz / 500 Hz / 1 kHz / 2 kHz / 4 kHz			<i>For light and matt measuring objects a high measuring rate may be required. For dark or bright measuring objects a slower measuring rate may be required (e.g. black lacquered surface) to improve the measuring result.</i>
Recording trigger / Output trigger	Level			<i>Continuous measurement output takes place as long as the selected level is applied. Level selection, see Chap. 7.3. Pulse duration must at least be one cycle time. The subsequent break must also be at least one cycle time.</i>
	Edge	infinite		<i>Edge selection. „0“ end trigger, „1 ... 16382“ values per trigger, „16383“ infinite trigger</i>
		manual	Number	
	Software	infinite		<i>Software triggering is started by clicking the button <code>Release trigger</code>. „0“ end trigger, „1 ... 16382“ values per trigger, „16383“ infinite trigger</i>
		manual	Number	
Inactive			<i>No triggering</i>	
Evaluation range	Start of range	0 ... 99 %	Value	<i>Set region of interest, i.e. only this range is used for measurement value recording. „Start“ value must be smaller than „end“ value.</i>
	End of range	1 ... 100 %	Value	<i>End of range (< 100 %) is set individually for the ILD1420-500 sensors.</i>

1) Available for the sensor models ILD1420-10/25/50.

Selection of peak	<i>First peak / Highest peak / Last peak</i>	<i>Defines which signal is used for the evaluation in the line signal.</i> <i>First peak: Nearest peak to sensor.</i> <i>Highest peak: standard, peak with the highest intensity.</i> <i>Last peak: widest peak to sensor.</i>	
Error handling	Error output, no measurement value	<i>The analog output supplies 3 mA instead of measurement value. The RS422 interface outputs an error value.</i>	
	Hold last value infinite	<i>Analog output and RS422 interface stop at the last valid value.</i>	
	Hold last value	1 ... 1024	Value
Measurement value averaging	<i>No averaging</i>		<i>Measurement values are not averaged.</i>
	<i>Moving N values</i>	2 / 4 / 8 ... 128	Value
	<i>Recursive N values</i>	2 ... 32768	Value
	<i>Median N values</i>	3 / 5 / 7 / 9	Value
Zeroing/ Mastering	<i>Inactive</i>		<i>Normal measurement value resp. Zeroing/Mastering is undone.</i>
	<i>Active</i>	<i>Value</i> <i>Indication e.g. of thickness of a master part.</i> <i>Value range 0 up to max. + 2 x measuring range</i>	
Reduction of data	<i>Value</i>		<i>Indicates the sensor which data is to be excluded from output, thus the data amount to be transmitted is reduced.</i>
Reduction is valid for	<i>RS422 / Analog</i>		<i>Interfaces to be used for undersampling are to be selected via the checkbox.</i>

A 4.2.3 Outputs

RS422	Baud rate	9.6 / 19.2 / 56.0 / 115.2 / 230.4 ... / 1000 kBps		Transmission speed, binary data format	
	Output data	Distance / Exposure time / Intensity / Sensor status / Measurement value counter / non-linearized focus / Timestamp / Video raw signal		Date to be transmitted are to be activated via the checkbox.	
Analog output	Standard scaling			Start of measuring range 4 mA, at end of measuring range 20 mA	
	Two point scaling	Start of range	Value	Always 2 points are taught which mark start and end of new measuring range. With two point scaling reversal of the output signal is possible.	
		End of range	Value		
Digital output	Inactive			Regulates the switching performance of the digital output (Error), see Chap. 5.4.8. Analog range: digital output switches when the scaled analog range is exceeded. Measuring range: The digital output is switched when the peak is not (entirely) in evaluation range (ROI). Limit monitoring: digital output switches when the limit is exceeded.	
	Analog range	NPN / PNP / PushPull / PushPullNeg			
	Measuring range	Limit monitoring			NPN / PNP / PushPull / PushPullNeg
		Limit	Value		
		Hysteresis	Value		
	Minimum holding period	Value			
Data output	Web interface / Analog / RS422			Decides on the used interface for measurement value output. A parallel physical measurement value output via RS422 and analog is not possible. If web interface was selected, no measurement values are output via RS422 or current output.	

		LED Output	Web interface		RS422	Current output
			Parametrization	Measurement chart		
Selected output interface	Web interface	yellow	•	•		
	RS422	green	•		•	
	Analog	red	•	•		•

A 4.2.4 System Settings

Unit on website	<i>mm / inch</i>		<i>Unit in measurement value display</i>	
Keylock	<i>Automatically</i>	<i>Range 1 ... 60 [min]</i>	Value	<i>The keylock starts after expiry of the defined time. Clicking the button <i>Refresh</i> extends the interval until keylock starts.</i>
		<i>Refresh</i>		
	<i>Active</i>			<i>The key <i>Select</i> does not respond to entries, independent of user level.</i>
<i>Inactive</i>			<i>The key <i>Select</i> is active, independent of user level.</i>	
Load & Save	Measurement settings	<i>Create setup / Setup 1 / ... / Setup 8</i>	<i>Load</i>	<i>Activates a saved measurement setting setup.</i>
			<i>Save</i>	<i>Saves changed measurement settings to an existing setup.</i>
			<i>Favorite</i>	<i>Selects a setup which is used after reboot of the sensor.</i>
			<i>Delete</i>	<i>Deletes a setup.</i>
			<i>Search</i>	<i>You load an existing setup from a PC or the like to the ILD 1420 with both buttons.</i>
			<i>Import</i>	
	<i>Export</i>	<i>Saves the setup on a connected PC or the like.</i>		
	Device settings	<i>Create setup</i>	<i>Load</i>	<i>Activates the saved device settings.</i>
			<i>Save</i>	<i>Saves changed device settings.</i>
			<i>Search</i>	<i>You load the device settings from a PC or the like to the ILD 1420 with both buttons.</i>
<i>Import</i>				
<i>Export</i>			<i>Saves the device settings on a connected PC or the like.</i>	

Import & Export	Create file	<i>Measurement settings</i>		<i>The measurement setting setups, the file with device settings and the boot file can be combined in one parameter set and exchanged with a PC or the like.</i>	
		<i>Boot setup</i>			
		<i>Device settings</i>			
	Search		<i>Button starts file manager to select a parameter set.</i>		
Check file	<i>Overwrite existing setups (with the same name)</i>		<i>Dialog prevents inadvertent overwriting of existing settings.</i>		
	<i>Apply settings of the imported boot setup</i>				
	<i>Transmit data</i>				
Access permission	Current access permission	<i>Value</i>		<i>Read only</i>	
	Logout / Login		<i>Button starts change of access permission.</i>		
	User level reboot	<i>Professional / User</i>		<i>Sets the user level the sensor starts with after re-boot. In this case MICRO-EPSILON recommends the selection user.</i>	
	Change password	Old password	<i>Value</i>		<i>Case-sensitive rules are observed for all passwords. Numbers are allowed. Special characters are not allowed. Maximum length is limited to 31 characters.</i>
		New password	<i>Value</i>		
		Repeat new password	<i>Value</i>		
	Change password				<i>Button causes change of password.</i>

	Measurement settings	<i>The settings for measuring rate, trigger, evaluation range, selection of peak, error handling, averaging, Zeroing/Mastering, reduction of data and setups are deleted. The 1st preset is loaded.</i>
Reset sensor	Device settings	<i>The settings baud rate, language, unit, keylock and echo mode are deleted and the default parameters are loaded.</i>
	Reset all	<i>By clicking the button the settings for the sensor, measurement settings, access permission, password and setups are deleted. The 1st preset is loaded.</i>
	Restart sensor	<i>By clicking the button the sensor is rebooted with the settings made in the favorite setup, see Chap. 7.6.4.</i>

 Selection required or checkbox

 *Value* Specification of a value required


i The settings will be effective, if you click on the button `Apply`. After the programming all settings must be permanently stored under a parameter set so that they are available again when the sensor is switched on the next time.



MICRO-EPSILON MESSTECHNIK GmbH & Co. KG
Königbacher Str. 15 · 94496 Ortenburg / Germany
Tel. +49 (0) 8542 / 168-0 · Fax +49 (0) 8542 / 168-90
info@micro-epsilon.de · www.micro-epsilon.com

X9751351-B011087MSC
© MICRO-EPSILON MESSTECHNIK





Assembly Instructions optoNCDT 1420

Warnings

Avoid unnecessary laser exposure to the human body. Turn off the sensor for cleaning and maintenance.

Connect the power supply and the display/output device in accordance with the safety regulations for electrical equipment. The power supply may not exceed the specified limits.

> Danger of injury, damage to or destruction of the sensor

Avoid shock and vibration to the sensor. Avoid continuous exposure to fluids. Avoid contact with aggressive materials (washing agent, penetrating liquids or similar).

> Damage to or destruction of the sensor

Mount the sensor only to the existing holes on a flat surface. Clamps of any kind are not permitted.

Attach the cable load-free, hold the cable after appr. 25 cm and hold the pigtail on the connector e.g. zip tie.

Caution - use of controls or adjustments or performance of procedures other than those specified may cause harm.

Read the instruction manual before using the sensor. The manual is available online or on the supplied CD.

CE Compliance

The following applies to the optoNCDT1420:
EU directive 2014/30/EU

The sensor fulfills the specification of the EMC requirements, if the instructions in the operating manual are followed.


Proper Environment

- Protection class: IP 65
- Operation temperature: 0 ... 50 °C
- Storage temperature: -20 ... 70 °C
- Humidity: 5 - 95 % (non-condensing)
- Pressure: atmospheric pressure

Laser Class

The sensors operate with a semiconductor laser with a wavelength of 670 nm (visible/red). The laser is operated in pulse mode, the maximum optical power is ≤ 1 mW. The pulse frequency depends on the adjusted measuring rate. The pulse duration of the laser is regulated depending on the measuring rate and reflectivity of the target and can be 0.3 up to 3999.6 μ s.

The sensors are classified for Laser Class 2 (II). Laser operation is indicated by LED state.




Laser label on sensor cable



Warning label on sensor

Control and Indicator Elements

LED State	Color	LED Output
Measuring object within sensor range	green	RS422 output
Mid range	yellow	Measuring value output off
Error - e.g. Poor target or out of range	red	Current output 4 ... 20 mA
Laser off	off	Sensor off, no supply




By factory default the key Select is - programmed with the functions Reset and Teaching. - only active for the first 5 minutes after power up. After that it will be automatically locked.

The function Masters can be transferred to the key via the web interface.

Pin Assignment


Pin	PCF1420-x/I	Description	Specification
3	green	RS422 Rx+	Serial input Internally terminated with 120 Ohm
4	yellow	RS422 Rx-	
5	gray	RS422 Tx+	Serial output Terminate externally with 120 Ohm
6	pink	RS422 Tx-	
7	red	+U _B	Power up 11 ... 30 VDC, typ. 24 VDC, P < 2 W
8	black	Laser on/off	Switch input Laser is active, if input is connected with GND
9	violet	Functional input	
10	brown	Error	Switch output I _{max} = 100 mA, U _{max} = 30 VDC, Programmable switching characteristic: (NPN, PNP, Push-Pull)
11	white	I _{OUT}	4 ... 20 mA R _{Load} = 250 Ohm: U _{OUT} 1 ... 5 V with U _B > 11 V R _{Load} = 500 Ohm: U _{OUT} 2 ... 10 V with U _B > 17 V
12	blue	GND	Ground potential Supply and signal ground
	Shield	Connector housing	Sensor housing Connect with potential equalization



Solder pin side female cable connector


The shield of the cable is connected with the housing of the sensor. The sensor cable is not cable carriers suitable. One end is molded on the sensor, the other end has free leads with ferrules or a pigtail with a M12 male connector.

Measuring Range, Start of Measuring Range




Current output	Digital value
3 mA	262077
4 mA (SMR)	643
12 mA (MR)	32760
20 mA (EMR)	64877
3 mA	262078


Proper Sensor Arrangement to Avoid Shadowing



Drawings




Mounting



Output Scaling

The teaching scales the analog output (4 to 20 mA) for a part of the measuring range. This allows you to optimize the resolution for the analog measurement range. Only the current and error output will be affected by the 2 point calibration. Therefore you define a new start and end for the measurement range. This teaching procedure can be performed live via the select key, via the multifunctional input or via the web interface.

Timing:



Factory Setting

- Current output
- Measurement frequency: 2 kHz
- Interface: 921.6 kbps
- Measuring range:
 - 100 % FSO: I = 20 mA, digital 64877
 - 0 % FSO: I = 4 mA, digital 643

Type	ILD 1420-	10	25	50	100	200
MR	mm	10	25	50	100	200
SMR	mm	20	25	35	50	60
EMR	mm	30	50	85	150	260
Y	mm	10	21	28	46	70

Range = Measuring range
SMR = Start of measuring range
MR = Midrange
EMR = End of measuring range
FSO = Full scale output

